


Walker Rider Lawnmowers

OWNER'S MANUAL

Safety, Assembly, Operating, and Maintenance Instructions

and ILLUSTRATED PARTS MANUAL

Model MBS26 (26 HP)
Model MBS (27 HP)



CE

TM

Please Read and Save These Instructions

For Safety, Read All Safety and Operation
Instructions Prior to Operating Machine

Effective Date: 09-15-10
P/N 2000-2



Foreword

Thank you. . .for purchasing a Walker mower. Every effort has been made to provide you with the most reliable mower on the market, and we are sure you will be among our many satisfied customers. If for any reason this product does not perform to your expectations, please contact your local dealer. Every customer is important to us. Your satisfaction is our goal.

Please. . .read this manual thoroughly! This manual is to be used in conjunction with the engine manufacturer's manual for the specific engine on the mower model you have purchased. Before you operate your new mower, please read this entire manual. Some of the information is crucial for proper operation and maintenance of this mower - it will help protect your investment and ensure that the mower performs to your satisfaction. Some of the information is important to your safety, and must be read and understood to help prevent possible injury to the operator or others. If anything in this manual is confusing or hard to understand, please contact your local authorized dealer or call our service department, at (970) 221-5614, for clarification before operating or servicing this mower.

This manual covers Model MBS26 with Kohler CH26 (26 HP) Electronic Fuel Injection (EFI) gasoline engine or optional Kohler Command CH740 (27 HP) gasoline engine.

All shields and guards must be in place for the proper and safe operation of this machine. Where they are shown removed in this manual, it is for illustration purposes only. **Do not operate this machine unless all shields and guards are in place.**

Specifications given are based on the latest information available at the time this manual was produced.

Walker Mfg. Co. is continually striving to improve the design and performance of its products. We reserve the right to make changes in specifications and design without thereby incurring any obligation relative to previously manufactured products.

Sincerely,
WALKER MANUFACTURING COMPANY

A handwritten signature in black ink that reads "Bob Walker". The signature is fluid and cursive.

Bob Walker, President

Table of Contents

Owner's Manual

General Information	1
HIGHLIGHTED INFORMATION	1
GLOSSARY	1
IDENTIFYING NUMBER LOCATIONS	1
ENGINE SERIAL NUMBER LOCATION	2
SERVICING OF ENGINE AND DRIVETRAIN COMPONENTS	2
Specifications	3
Component Identification	6
Safety Instructions	10
BEFORE OPERATING	10
OPERATING	11
MAINTENANCE	13
SAFETY, CONTROL, AND INSTRUCTION DECALS	14
Assembly Instructions	16
SETUP INSTRUCTIONS	16
Battery Service	16
Wet Battery Service	16
Dry Battery Service	16
Battery Charging	17
Mower Deck Assembly	17
Deck Caster Wheels Installation	17
Deck Discharge Shield Installation (DSD60)	18
PTO Shaft Guard Installation	18
Tilt-Up Roller Wheel Installation	18
Mower Deck Installation on Tractor	18
Deck Installation	18
Deck Leveling	21
PREOPERATING CHECKLIST	22
Operating Instructions	24
CONTROL IDENTIFICATION, LOCATION, AND FUNCTION	24
Ignition Switch	24
Engine Choke (Model MBS Only)	25
Engine Throttle	25
Body Latch	25
Forward Speed Control (FSC)	25
Steering Levers	26
Blade Clutch (PTO)	26
Parking Brake	26

Oil Pressure Warning Light	27
Engine Service Light (Model MBS26 Only)	27
Over Temperature Warning Light	27
Transaxle Lockout Rods	28
Hourmeter	28
STARTING THE ENGINE	30
ADJUSTING GROUND	
SPEED AND STEERING	30
ENGAGING THE MOWER	32
STOPPING THE MACHINE	33
FUEL SELECTOR VALVE	34
ADJUSTING CUTTING HEIGHT	34
Transport Position	34
TRANSAXLE LOCKOUTS	35
RECOMMENDATIONS FOR MOWING	35
RECOMMENDATIONS FOR TILT-UP DECK OPERATION/TRANSPORT	37
Maintenance Instructions	38
MAINTENANCE SCHEDULE CHART	38
IMPORTANT TIPS FOR CARE OF THE KOHLER ENGINE	39
Fuel System	39
Starting/Stopping	39
Cooling System	39
Air Cleaner System	39
Oil	39
LUBRICATION	40
Engine Oil	40
Engine Break-In Oil	40
Checking Engine Crankcase Oil Level	40
Changing Engine Crankcase Oil/Oil Filter	40
Mower Deck Spindle Lubrication	42
DRD52 or DSD60 Mower Deck Lubrication	42
Transaxle Lubrication	42
Transaxle Oil and Filter Change	42
Grease Fitting and Oil Point Lubrication	43
CLEANING	46
Engine Air Cleaner System	46
Cummins/Fleetguard OptiAir™ Air Cleaner	46
Engine Cooling System	48
Air Intake System	48
Cylinder Head Cooling Fins	48
Grass Buildup in Mower Housing	49
Transaxle Cooling Fins	51

Table of Contents

CHECKING/SERVICING	52
Security of Air Filtration Components	52
Battery	52
Electrolyte Level	52
Cleaning the Terminals	53
Charging the Battery	53
Tire Pressure	53
Wheel Nuts Torque	53
Sharpen Mower Blades	53
Drive Belts	54
Spark Plugs	54
Fuel Lines and Clamps	54
PTO U-Joints	55
Blade Brake Action	55
Safety Switch System	55
Forward Speed Control Friction Lock	55
REPLACING/REPAIRING	56
Drive Belts	56
Engine/PTO Belt	57
Ground Drive Belt	58
Fuel Filter - Model MBS26	59
Fuel Filter - Model MBS	59
Mower Blades	59
ADJUSTMENTS	60
Transmission Control	60
Steering Lever Position Adjustment	60
Steering Handles Adjustment	61
Neutral Position Adjustment	61
Full Forward Speed Adjustment	62
Straight Tracking Adjustment	63
FSC Switch - Neutral Adjustment	63
Forward Speed Control	
Friction Adjustment	64
Blade Clutch (PTO)	65
Clutch Engagement/Belt Tension	65
Clutch Disengagement/Brake Action	66
Idler Pulley Maximum Travel Adjustment	66
Blade Brake Band Adjustment	67
ELECTRICAL SYSTEM	67

Illustrated Parts Manual

TRACTOR AND DECK DECALS	68
BODY / CHASSIS ASSEMBLY	70
MAIN COMPONENT POWER TRANSMISSION	72
ENGINE GROUP (MODEL MBS26)	74
ENGINE GROUP (MODEL MBS)	76
HYDROSTATIC GROUND	
DRIVE ASSEMBLIES	78
STEERING CONTROL ASSEMBLIES	80
ELECTRICAL ASSEMBLY (MODEL MBS26)	82
ELECTRICAL ASSEMBLY (MODEL MBS)	84
60 INCH COMPLETE CARRIER	
FRAME ASSEMBLY	86
DSD60 DECK ASSEMBLY	88
52 INCH COMPLETE CARRIER	
FRAME ASSEMBLY	90
DRD52 DECK ASSEMBLY	92
MULCHING KIT	94
WIRING SCHEMATIC (MODEL MBS26)	96
WIRING SCHEMATIC (MODEL MBS)	98
Warranty	99

General Information

HIGHLIGHTED INFORMATION

Walker Manufacturing recommends that any service requiring special training or tools be performed by an authorized Walker Mower Dealer. There are several general practices to be aware of in the area of safety. Most accidents associated with the operation or maintenance of a Walker Mower are caused by disregarding basic safety precautions or specific warnings. Such accidents, in most cases, can be prevented by being aware of the dangers present.

Information of special importance has been highlighted in bold type in this manual. Refer to **Safety Instructions** for the meanings of **DANGER**, **WARNING**, **CAUTION**, **IMPORTANT**, and **NOTE**.

GLOSSARY

There are many terms that are either unique to this equipment or that are used as acronyms. The following terms and their definitions will help while using this manual:

- **DECK** is the mowing attachment mounted on the front of the tractor which includes the carrier frame, deck housing, blade spindles, and cutter blades.
- **ELECTRONIC CONTROL UNIT (ECU)** controls engine functions such as spark timing, fuel/air ratio, etc.
- **FORWARD SPEED CONTROL (FSC)** controls the maximum forward speed of the tractor; functioning as a cruise control.
- **GROUND DRIVE** refers to the dual transaxles which drive the main wheels.
- **LEFT HAND (LH)** refers to the left-hand side of the tractor when the operator is seated facing forward in the tractor seat.
- **POWER TAKE-OFF (PTO)** transmits engine power to run the cutter blades.
- **RIGHT HAND (RH)** refers to the right-hand side of the tractor when the operator is seated facing forward in the tractor seat.
- **SIDE DISCHARGE (SD)** mows but does not collect the mowed material.
- **STEERING LEVERS** steer the tractor by controlling the two transaxles.

- **TRACTOR** is the prime mover, including the engine, drive train, operator seat, and controls to operate the mower.
- **TRANSAXLE** transmits and controls power from the ground drive belt to the main drive wheel.
- **TRANSAXLE LOCKOUT RODS** release the transaxles to permit freewheeling the tractor.


IDENTIFYING NUMBER LOCATIONS

The tractor serial number plate is affixed to the tractor body just below the left rear corner of the seat. The mower deck serial number plate is affixed alongside the angle iron framing on the LH side of the LH mower blade drive. Model and serial numbers are helpful when obtaining replacement parts and maintenance assistance. For ready reference, please record these numbers in the space provided.


Tractor Model No.	_____
Tractor Serial No.	_____
Deck Serial No.	_____
Engine Model No.	_____
Engine Serial No.	_____
Date of Purchase	_____

Fill In By Purchaser

General Information




Tractor Serial Number Location



Mower Deck Serial Number Location

ENGINE SERIAL NUMBER LOCATION

Refer to the engine manual that accompanies this manual for the location of the engine serial number. For the mower model(s) covered by this manual, an engine manual is available from Kohler covering the Kohler engines.



Engine Serial Number Location

SERVICING OF ENGINE AND DRIVETRAIN COMPONENTS

The detailed servicing and repair of the engine and transaxle are not covered in this manual. Only routine maintenance and general service instructions are provided. For the service of these components during the limited warranty period, it is important to find a local, authorized servicing agent of the component manufacturer. **Any unauthorized work done** on these components during the warranty period **may void the warranty**. If you have any difficulty finding an authorized outlet or obtaining warranty service, please contact our Service Department for assistance:

Walker Manufacturing Company
5925 E. Harmony Road
Fort Collins, CO 80528
1-970-221-5614

Service manuals are available for each of these components from their respective manufacturers as follows:

Kohler Engines **Kohler Company**
Kohler, WI 53044
800-544-2444
www.kohlerengines.com

Transaxles **Hydro-Gear**
1411 South Hamilton St.
Sullivan, IL 61951

Specifications

MODEL	MBS	MBS26
ENGINE		
Manufacturer/Model	Kohler Command CH740, 2 Cyl. OHV (Air-Cooled)	Kohler Command Pro® CH26, 2 Cyl., Gasoline (Air- Cooled), Electronic Fuel Injection (EFI)
Displacement	44.0 cu. in. (725 cc)	44.0 cu. in. (725 cc)
HP (@ 3600 RPM)	27.0	26.0
Max. RPM (No Load)	3600 ± 100	3750
Governed RPM	3600 ± 100	3600 ± 100
Max. Torque [ft-lb (N·m) @ RPM]	29.5 (40.0) @ 2400	40 (54.2) @ 2800
Idle RPM	1200 ± 75	1200 ± 75
Spark Plug Type	Champion® RC14YC	Champion® RC12YC
Spark Plug Gap	.030 in. (0.76 mm)	.030 in. (0.76 mm)
Crankcase Capacity	1.9 qts (1.8 liters)	1.9 qts (1.8 liters)
Crankcase Lubricant	SG/SH/SJ or Higher Grade Oil Only with 10W-30 Viscosity Above 0° F (-18° C) or 5W-20 or 5W-30 below 32° F (0° C)	SG/SH/SJ or Higher Grade Oil Only with 10W-30 Viscosity Above 0° F (-18° C) or 5W-20 or 5W-30 below 32° F (0° C)
Oil Filter	12 050 01 5 (2-1/2)	12 050 01 5 (2-1/2)
Fuel Tank Capacity	10 Gallons (38.0 liters) Two Independent Five (5) Gal- lon Tanks with Selector Valve	10 Gallons (38.0 liters) Two Independent Five (5) Gal- lon Tanks with Selector Valve
Fuel	Automotive Grade Unleaded Gasoline (87 Octane) or Gasohol (Up to 10% Ethyl Alcohol, 90% Unleaded Gasoline by Volume)	Automotive Grade Unleaded Gasoline (87 Octane) or Gasohol (Up to 10% Ethyl Alcohol, 90% Unleaded Gasoline by Volume)
Cooling System	Air Cooled	Air Cooled
ELECTRICAL SYSTEM		
Battery	12 Volt (340 CCA)	12 Volt (340 CCA)
Charging System	15 Amp Alternator	Flywheel Alternator
Charging Output	15 Amp DC (Regulated)	25 Amp DC (Regulated)
System Polarity	Negative Ground	Negative Ground
Ignition	Electronic Capacitive Discharge	Electronic Capacitive Discharge
Starter	12 Volt Electric Key and Solenoid Operated	12 Volt Electric Ring-Gear Type, Solenoid Operated
Interlock Switch	Ignition Lockout by Seat Switch, Transmission Neutral and Blade Clutch	Ignition Lockout by Seat Switch, Transmission Neutral and Blade Clutch
Circuit Breaker	Manual Reset (30A)	Manual Reset (30A)

Specifications

MODEL	MBS	MBS26
TRANSMISSION		
Manufacturer/Model	Dual, Independent Hydro-Gear Integrated Transaxles	Dual, Independent Hydro-Gear Integrated Transaxles
Steering	Hand Lever Control / Individual Wheel	Hand Lever Control / Individual Wheel
Forward Speed Control	Precision Friction Lock Lever, Cruise Control, with Neutral-Park Position	Precision Friction Lock Lever, Cruise Control, with Neutral-Park Position
Service Brake	Dynamic Braking through Transaxles	Dynamic Braking through Transaxles
Parking Brake	(Internal) Mechanical Lockout for each Transaxle (Single Lever Control)	(Internal) Mechanical Lockout for each Transaxle (Single Lever Control)
Neutral	Transmission Release by Manual Dump Valve	Transmission Release by Manual Dump Valve
Final Drive	Direct Drive Axle from Transaxle	Direct Drive Axle from Transaxle
Transmission Fluid		
Factory Service	20W-50 Multi-Viscosity Motor Oil (Minimum SL Grade Oil)	20W-50 Multi-Viscosity Motor Oil (Minimum SL Grade Oil)
Transmission Fluid Capacity	79 fl oz (2336 ml)	1 qt (1 liter)
Transmission Cooling	Cooling Fan Mounted on Drive Pulley	Cooling Fan Mounted on Drive Pulley
Ground Travel Speed		
Forward m.p.h. (km/h)	0-9 (0-14) Infinitely Variable	0-9 (0-14) Infinitely Variable
Reverse m.p.h. (km/h)	0-5 (0-8) Infinitely Variable	0-5 (0-8) Infinitely Variable
BLADE DRIVE		
PTO Shaft	Sliding Spline Shaft with Two (2) High-Speed U-Joints	Sliding Spline Shaft with Two (2) High-Speed U-Joints
Blade Spindle	Each Blade (3) Mounts Directly on Belt Driven Spindles	Each Blade (3) Mounts Directly on Belt Driven Spindles
Blade Drive Clutch and Brake	Manual Belt Tightener Clutch and Band Brake [Stops Blades within Five (5) Seconds of Disengagement]	Manual Belt Tightener Clutch and Band Brake [Stops Blades within Five (5) Seconds of Disengagement]
Max. Blade Speed [20-1/2 in. (52 cm) Blade] @ 3600 RPM Engine	3200 RPM [18300 FPM (5578 m/min)]	3200 RPM [18300 FPM (5578 m/min)]
TIRE SIZE		
Deck Caster Wheel	13 x 5.00-6 Pneumatic (4-Ply)	13 x 5.00-6 Pneumatic (4-Ply)
Drive	22 x 10.50-12 (4-Ply Low-Profile)	22 x 10.50-12 (4-Ply Low-Profile)
Rear	13 x 5.00-6 (4-Ply)	13 x 5.00-6 (4-Ply)


Specifications

MODEL	MBS	MBS26
TIRE PRESSURE		
Deck Caster Wheel	20 PSI (137 kPa)	20 PSI (137 kPa)
Drive	15 PSI (103 kPa)	15 PSI (103 kPa)
Rear	20 PSI (137 kPa)	20 PSI (137 kPa)
DIMENSIONS (Tractor and Mower)		
Length	100-1/4 in. (255 cm)	100-1/4 in. (255 cm)
Width		
60 in. (152 cm) SD Model (with Deflector)	62 in. (158 cm)	62 in. (158 cm)
Height	47-1/2 in. (121 cm)	47-1/2 in. (121 cm)
Wheel Base (Tractor)	42-5/8 in. (109 cm)	42-5/8 in. (109 cm)
Tread Width (Tractor)	36-1/2 in. (93 cm)	36-1/2 in. (93 cm)
MOWER DECK		
Width of Cut	52 or 60 in. (132 or 152 cm)	52 or 60 in. (132 or 152 cm)
Cutting Height	1 to 5 in. (3 to 13 cm)	1 to 5 in. (3 to 13 cm)
Height Adjustment	17 Positions - 1/4 in. (1 cm) Increments	17 Positions - 1/4 in. (1 cm) Increments
Blade Size		
52 in. (132 cm) RD Model	18.3 in. (46 cm) Three (3) Clockwise-Rotating Blades	18.3 in. (46 cm) Three (3) Clockwise-Rotating Blades
60 in. (152 cm) SD Model	20-1/2 in. (52 cm) Three (3) Clockwise-Rotating Blades	20-1/2 in. (52 cm) Three (3) Clockwise-Rotating Blades
Deck Suspension	Torsion-Flex Frame with Caster Wheels and Counterweight Springs	Torsion-Flex Frame with Caster Wheels and Counterweight Springs
CURB WEIGHT (Approximate)		
Tractor Only	730 lb (331 kg)	735 lb (333 kg)
SD Tractor and 60 in. SD Deck	1110 lb (503 kg)	1115 lb (506 kg)
DRIVE BELTS		
Engine PTO	Walker P/N 2230	Walker P/N 2230
Ground Drive	Walker P/N 2248	Walker P/N 2248
SEAT	Contour-Molded, with Nylon Backed Vinyl Cover and Integral Foam Cushion (Suspension)	Contour-Molded, with Nylon Backed Vinyl Cover and Integral Foam Cushion (Suspension)
FRAME/BODY CONSTRUCTION		
Frame/Body	3/16 Plate Steel/14 Gauge Sheet Steel	3/16 Plate Steel/14 Gauge Sheet Steel
Deck	11 Gauge Steel	11 Gauge Steel

NOTE: The manufacturer reserves the right to make changes in specifications shown herein at any time without notice or obligation.


Component Identification

NOTE: Control Identification shown in **Operating Instructions** section.




Front View and Right Side View

Component Identification




Rear View and Left Side View

Component Identification



Top View (Body Raised) Model MBS26

Component Identification



Top View (Body Raised) Model MBS

Safety Instructions

Pay particular attention to any information labeled **DANGER, WARNING, CAUTION, IMPORTANT,** and **NOTE** in this manual.

When you see the Safety Alert Symbol (), read, understand, and follow the instructions. Failure to comply with safety instructions may result in personal injury.

The seriousness or degree of importance of each type of information is defined as follows:

DANGER

An **IMMEDIATE** hazard that **WILL** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.

WARNING

A **POTENTIAL** hazard that **COULD** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.

CAUTION

Possible hazards or unsafe practices that **MAY** result in **MODERATE** personal injury or property damage, or machine damage, if warning is ignored and proper safety precautions are not taken.

IMPORTANT: Identifies mechanical information demanding special attention, since it deals with the possibility of damaging a part or parts of the machine.

NOTE: Identifies information worthy of special attention.

Walker Manufacturing cannot predict every potentially dangerous situation. Therefore, items labeled as such in this manual do not cover all conceivable situations. Any person using procedures, tools, or control techniques not recommended by Walker Manufacturing must take full responsibility for safety.

The Walker Rider Lawnmower has been designed with many safety features to protect the operator from personal harm or injury. However, it is necessary for the operator to use safe operating procedures at all times. **Failure to follow safety instructions contained in this manual may result in personal injury or damage to equipment or property.**

If you have any questions concerning setup, operation, maintenance, or safety, please contact your authorized Walker Mower Dealer or call Walker Manufacturing Company at (970) 221-5614.

BEFORE OPERATING

1. **Read and understand the contents of this Owner's Manual before starting and operating the machine.** Become thoroughly familiar with all machine controls and how to stop the machine and disengage the controls quickly. Replacement Owner's Manuals are available by sending the Model and Serial Number to:

Walker Manufacturing Company
5925 East Harmony Road
Fort Collins, CO 80528
2. **Never allow children to operate rider mower.** Do not allow adults to operate without proper instruction.
3. **Clear the area to be mowed of any foreign objects** which may be picked up and thrown by cutter blades. Pick up all sticks, stones, wire, and any other debris.
4. Keep everyone, especially children and pets, a safe distance away from the area being mowed. **Do not mow with bystanders in the area.**
5. Do not operate the machine barefoot or wearing sandals, sneakers, tennis shoes, or similar lightweight footwear. **Wear substantial protective footwear.**

Safety Instructions

6. Do not wear loose fitting clothing that could get caught in moving parts. Do not operate this machine while wearing shorts; **always wear adequate protective clothing**, including long pants. Wearing safety glasses, safety shoes, and a helmet is advisable and required by some local ordinances and insurance regulations.
7. Prolonged exposure to loud noise can cause impairment or loss of hearing. **Operator hearing protection is recommended.** Wear a suitable hearing protective device, such as earmuffs or earplugs.
8. **Keep all protective shields and safety devices in place.** If a protective shield, safety device, or decal is damaged, unusable, or missing, repair or replace it **before** operating the machine.
9. **Be sure interlock switches are functioning correctly**, so the engine cannot be started unless the Forward Speed Control lever is in the **NEUTRAL-PARK** position, and the PTO clutch is in the **DISENGAGED** position. Also, the engine should stop if the operator lifts off the seat with either the Forward Speed Control (FSC) out of the **NEUTRAL-PARK** position or the PTO clutch in the **ENGAGED** position.

NOTE: There is a 1 to 1-1/2 second time delay function on the seat switch to avoid engine power interruption when driving over bumps.

10. **Handle gasoline with care.** Gasoline is highly flammable and its vapors are explosive:
 - a. Use an approved fuel container.
 - b. Never add fuel to a running engine or hot engine (allow hot engine to cool several minutes).
 - c. Keep matches, cigarettes, cigars, pipes, open flames, or sparks away from the fuel tanks and fuel container.
 - d. Always fill the fuel tank(s) outdoors using care. Fill to about one inch from the top of the tank. Use a funnel or spout to prevent spilling.
 - e. Replace the machine fuel cap(s) and container cap securely and clean up any spilled fuel before starting the engine.

11. **Never attempt to make any adjustments while the engine is running**, except where specifically instructed to do so.
12. The electrical system battery contains sulfuric acid. Avoid any contact with skin, eyes, and clothing. Keep the battery and acid out of reach of children.



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

OPERATING

1. **Operate the mower only in daylight** or in good artificial light with good visibility of the area being mowed.
2. Sit on the seat when starting the engine and operating the machine. Keep feet on the deck footrests at all times when the tractor is moving and/or mower blades are operating. **Never operate the tractor without deck or implement installed.**
3. For a beginning operator, **learn to steer (maneuver) the tractor with a slow engine speed before attempting any mowing operation.** Be aware that, with the front mounted mower configuration, the back of the tractor swings to the outside during turns.



DANGER

Do not mow around overhanging tree branches or bushes at the same height as the operator's torso and head where inadvertent contact may cause injury.

4. Remember, for an emergency stop, the forward motion of the tractor can always be stopped by pulling the Forward Speed Control (FSC) into the **NEUTRAL-PARK** position.

Safety Instructions

5. In case the transmission drive belt breaks during operation, and if the machine is on a slope, the machine will freewheel down the slope. **To maintain control**, immediately (1) Release the steering levers and simultaneously (2) Move the FSC to the **NEUTRAL-PARK** position. When the machine is stopped or moving slowly, engage the parking brake.

NOTE: This is exactly the same procedure used to normally stop and park the machine.

6. Disengage the blade clutch and put the FSC in the **NEUTRAL-PARK** position before starting the engine (an ignition interlock switch normally prevents starting of the machine if these controls are in the **OPERATING** position).
7. **Do not operate machine if the operator presence safety switch system is not working.** Verify proper operation by having the operator lift off the seat with the engine running and moving two controls, one at a time; (1) Move the FSC lever out of the **NEUTRAL-PARK** position, and (2) Engage the PTO Clutch. Moving either control should stop the engine after a 1-1/2 second delay.
8. **Do not run the engine in a confined area without adequate ventilation.** Exhaust fumes are hazardous and can be deadly.
9. **Do not carry passengers** - maximum seating capacity is one (1) person.
10. Watch for holes, rocks, and roots in the terrain and for other hidden hazards. When mowing tall grass, mow higher than desired to expose any hidden obstacles. Then, clean the area and mow to the desired height.
11. **Avoid sudden starts or stops.** Before backing the machine up, look to the rear to be sure no one is behind the machine. Watch carefully for traffic when crossing or working near roadways.
12. Disengage the blade drive when transporting the machine across drives, sidewalks, etc. **Never raise the mower deck while blades are rotating.**



DANGER

Do not mow or dump grass within 5 feet (1.5 meters) of an embankment or retaining wall with drop off.

13. **The maximum recommended side slope operating angle is 20 degrees or 33% grade.** When operating the machine on a slope, reduce speed and use caution to start, stop, and maneuver. To prevent tipping or loss of control of the machine, avoid sharp turns or sudden changes in direction.
14. **Never adjust cutting height while the mower is moving.** Before adjusting cutting height or servicing, move the Forward Speed Control (FSC) into the **NEUTRAL-PARK** position, engage the parking brake, and disengage the blade clutch (PTO). Tractor should **not** be moving while adjusting cutting height.

NOTE: The clutch brake should normally stop drive line rotation within five (5) seconds of disengaging the PTO clutch.
15. **Do not operate with the grass deflector chute removed.** Keep the deflector in the lowest possible position.
16. When using the tilt-up deck, **observe the following recommendations:**
 - a. Do not move tractor with deck in tilt-up position.
 - b. Never tilt body forward with deck in tilt-up position.
17. **In case of a clogged or plugged mower deck:**
 - a. Disengage the blade clutch (PTO), set the parking brake, and turn the engine off before leaving the seat.
 - b. **LOOK** to make sure blade drive shaft movement has stopped before trying to unclog the system.
 - c. Disconnect the spark plug wires.
 - d. Never place hands under the deck - use a stick or similar tool to remove clogged material.

Safety Instructions

18. If the cutting blades strike a solid object or the machine begins to vibrate abnormally, **immediately disengage the blade clutch (PTO), stop the engine, and wait for all moving parts to stop.** To prevent accidental starting, disconnect the spark plug wires. Thoroughly inspect the mower and repair any damage before restarting the engine and operating the mower. Make sure cutter blades are in good condition and blade bolts are torqued to 64 ft-lb (86.8 N·m).
19. **Do not touch the engine or muffler while the engine is running** or immediately after stopping the engine. These areas may be hot enough to cause serious burns.
20. When leaving the machine unattended, **disengage the blade clutch (PTO), stop the engine, and remove the key.**

MAINTENANCE


1. To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the spark plug wires.
2. **To reduce fire hazards,** keep the engine free of grass, leaves, excessive grease, and dirt.
3. Keep all nuts, bolts, and screws tight to ensure the machine is in a safe, working condition. Check the blade mounting bolts frequently, making sure they are tight.
4. **Perform only maintenance instructions described in this manual.** Unauthorized maintenance operations or machine modifications may result in unsafe operating conditions.
5. If the engine must be running to perform a maintenance adjustment, keep hands, feet, and clothing away from moving parts. **Do not wear jewelry or loose clothing.**
6. **Always use the proper engine service manual when working on the engine.** Unauthorized maintenance operations or modifications to the engine may result in unsafe operating conditions.
7. Altering the equipment or engine in any manner which adversely affects its operation, performance, durability, or use will **VOID the warranty** and may cause hazardous conditions.
8. Never attempt to disconnect any safety devices or defeat the purpose of these safety devices.
9. Do not change the engine governor settings or overspeed the engine. The governor has been factory-set for maximum-safe engine operating speed.
10. **Use genuine factory replacement parts.** Substitute parts may result in product malfunction and possible injury to the operator and/or others.
11. **Use care when charging the battery** or performing maintenance on the battery and electrical system:
 - a. Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.
 - b. Charge the battery in a well-ventilated space, so gases produced while charging can dissipate. Make sure the battery vents in the caps are open.
 - c. Keep sparks, flames, and smoking materials away from the battery at all times. To avoid sparks, use care when removing battery cables from posts.
 - d. Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.

IMPORTANT: Keep all applicable manuals immediately accessible to anyone who may operate or service this machine.


Safety Instructions

SAFETY, CONTROL, AND INSTRUCTION DECALS

Safety, Control, and Instruction Decals are installed on the machine;
if any are missing, illegible, or damaged, a replacement should be ordered and installed before
putting the machine into operation. The Decal Part Number is listed below and in the Parts Section.



LH Fender (2802-1)
Model MBS Only



LH Fender (2802-3)
Model MBS26 Only



Each End of Mower Deck (5808)




DSD60 Deck Discharge Shield (5848)




Deck Housing (2724-7)




Deck Carrier Frame (8647)



RH Fender (2802-2)



Center Body Behind
Transaxles (9804)




On Engine (6810)




Rear Body,
Above Muffler (5805)



Deck Carrier Frame (8653)



PTO Guard (8746)




Engine Shroud (5855)


Safety Instructions

SAFETY, CONTROL, AND INSTRUCTION DECALS


Safety, Control, and Instruction Decals are installed on the machine;
if any are missing, illegible, or damaged, a replacement should be ordered and installed before
putting the machine into operation. The Decal Part Number is listed below and in the Parts Section.




Deck Housing, DSD60 (2749-2)




Deck Housing, DRD52 (2749-1)




Rear Body, Underside
(2107-4)




Front Body Adjacent to RH Steering Lever, MBS26 (2807-2)




Front Body Adjacent to
RH Steering Lever, MBS (2807-1)




Deck Carrier Frame (2748)



Deck Housing (8653-1)



On Transfer Mount, MBS
(2010-4)



On Transfer Mount, MBS26
(2010-5)



Flex Coupling Guard (4107-1)

Assembly Instructions

SETUP INSTRUCTIONS

Walker Mowers are shipped partially assembled to our distribution network, and are typically assembled by the selling dealer. For any additional assembly besides the following, contact your Walker dealer.

Battery Service



CAUTION

Important Battery Service, Installation, and Changing Tips for MBS26:

- Do not allow the battery cables to touch opposing terminals. When connecting battery cables attach the positive (+) cable to positive (+) battery terminal first, followed by negative (-) cable to negative (-) battery terminal.
- Never start the engine when the cables are loose or poorly connected to the battery terminals.
- Never disconnect battery while engine is running.
- Never use a quick battery charger to start the engine.
- Never “jump start” the engine using another source. Electricity fluctuations can damage the ECU (Electronic Control Unit).
- Always disconnect negative (-) battery cable lead before charging battery, and also unplug harness from ECU before performing any welding on equipment.

Raise mower body up for battery access. Check the battery for electrolyte level and charge. The electrolyte level should be at the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above plates]. If the specific gravity is less than 1.225, the battery needs charging. If the battery has been shipped dry, or is wet but needs service, refer to the following instructions.

IMPORTANT: Make sure battery is securely mounted in the frame. A loose battery may cause damage to the case resulting in acid leakage and severe damage to the machine. A hazard may be created by damage to critical working parts and safety systems.

Wet Battery Service

If the battery has been shipped wet, but the electrolyte level is low or the battery needs to be charged then:

1. Fill each battery cell with drinking water to the bottom of the vent wells.
2. Charge battery. Refer to *Battery Charging* in this section.

Dry Battery Service



DANGER

Activating a battery can be dangerous. The battery should be taken to a reliable service station, battery store, or power equipment dealer where a trained technician can activate the battery safely. DO NOT attempt to activate the battery unless you are experienced in battery service work. The following activation and charging instructions are provided for use by a trained battery technician.



DANGER

Battery electrolyte is a poisonous and corrosive sulfuric acid solution.

- Avoid spillage and contact with skin, eyes, and clothing - causes severe burns.
- To prevent accidents, wear safety goggles and rubber gloves when working with electrolyte.
- Neutralize acid spills with baking soda and water solution.

To fill (activate) battery with electrolyte (if battery has been shipped dry):

1. Remove the battery hold-down bar, disconnect the battery cables and lift the battery out of the tray.

IMPORTANT: Battery must be removed from the mower before filling with electrolyte.

Assembly Instructions

IMPORTANT: Obtain and use only battery grade sulfuric acid electrolyte with a 1.265 specific gravity to activate the battery. **DO NOT** use water or any other liquid during initial activation.

2. Remove the filler caps and carefully fill each cell until the electrolyte is just above the plates.
3. After the battery is filled with electrolyte, replace the filler caps and charge the battery. Refer to *Battery Charging*.

Battery Charging



BATTERIES PRODUCE EXPLOSIVE GASES

- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open after the battery is filled with acid (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

IMPORTANT: On MBS26 models, always disconnect the negative (-) battery terminal before charging. Failure to do so can result in damage to the ECU.

1. Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.
2. After charging the battery, adjust the electrolyte level to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].

IMPORTANT: **DO NOT** overfill the battery. Electrolyte will overflow through the vented caps onto parts of the machine and **WILL** result in severe corrosion.

3. Install battery.

Mower Deck Assembly

Deck Caster Wheels Installation

1. Remove the bolts and washers from each deck caster wheel.
2. Install wheel on fork using bolts and washers.

NOTE: Valve stem and grease zerk should face to the inside of machine.

3. Tighten the bolts and washers.



Deck Caster Wheel Installation

Assembly Instructions

Deck Discharge Shield Installation (DSD60)

Attach the deck side discharge shield by positioning the shield hinge lug in **front** of the deck mount and fastening with two (2) 3/8-16 x 1-1/4 in. bolts, 3/8-16 ESNA nuts, and 3/8 in. wave spring washers. The wave washers fit between the two hinging surfaces. Tighten the nuts until the shield moves freely but is not loose.



WARNING


DO NOT operate the machine without the grass deflector chute attached and in the lowest possible position.



Deck Discharge Shield Installation

PTO Shaft Guard Installation


Position the shaft guard as shown and mount with two (2) 1/4-20 x 1/2 in. bolts.



PTO Shaft Guard Installation

Tilt-Up Roller Wheel Installation

Mount the two (2) tilt-up roller wheels on the brackets on the rear skirt of the deck housing using the P/N 8490 axle bolt, 3/8 in. wave spring washer and 3/8-16 in. Whiz locknut. Tighten the axle bolt until the wheel rolls freely, but is not loose.



Roller Wheel Installation (DSD60 Shown)

Mower Deck Installation on Tractor

Deck Installation


1. Lightly grease each deck support arm (2) on the tractor. Refer to **Mower Deck Installation** photo for location of deck support arm.
2. Engage the LH deck carrier frame tube socket first on the tractor support arms and then the RH tube socket, slide the deck onto the support arms approximately 3 in. (76 mm).



Retract Coupler Ring


Assembly Instructions

3. Retract spring-loaded coupler ring on the PTO Tube (provided in Owner's Packet) and insert coupler tool. Refer to **Quick Coupler Installation Tool** photo.




Quick Coupler Installation Tool

4. Reaching under the tractor, join the PTO tube to the PTO shaft (align arrow decals). Slide the PTO tube onto the spline shaft on the tractor PTO drive shaft.



**Mower Deck Installation
(PTO Shaft Connection)**

5. Slide the deck the rest of the way on the deck arms.



Mower Deck Installation

6. Install the lynch pin through the hole on the end of each support arm to lock the deck in place (refer to **Deck Counterweight Spring Installation** photo). Two (2) lynch pins are included in the owner's packet of materials.
7. Remove Installation Tool from coupler ring and make sure the ring has "snapped" securely on the spline shaft.

IMPORTANT: DO NOT operate tractor with Quick Coupler Installation Tool installed.


IMPORTANT: To prevent damage to the mower, make sure the PTO shaft assembly is securely locked on the tractor, with the locking balls fully seated in the groove and the ring in the full forward position (refer to the **Coupler Ring "Locked" Position** photo). After installation, pull on the shaft to check for security.



Coupler Ring "Locked" Position

Assembly Instructions

8. Raise the mower body (instead of lifting the front of deck) and clip the counterweight springs to the receptacle on front of body. Lower the body to tension the springs. (Refer to **Deck Counterweight Spring Installation** photo.)
9. With the counterweight springs connected, the weight on the deck caster wheels should be 15 to 25 lb (6.8 to 11.3 kg); this adjustment is preset at the factory. If required, the spring tension can be adjusted by tightening or loosening the elastic stop nuts located underneath the lower spring hook, or contact your local dealer if additional help is required. Refer to **Deck Counterweight Spring Installation** photo.



Deck Counterweight Spring Installation

Assembly Instructions

Deck Leveling

1. Position mower on a smooth, level surface. Set the cutting height to the highest position - 5 in. (127 mm) - for easy access under the deck to measure blade height. Refer to **ADJUSTING CUTTING HEIGHT** in Operating Instructions.

NOTE: A block of wood cut **5 in. (127 mm)** high is a convenient gauge to measure blade height above ground during the leveling process.




WARNING

The machine must be shut off during this procedure.

2. Check the side-to-side level. **Rotate the outside blades sideways** and measure the distance from blade tip to ground on each side. If measurements vary more than 1/8 in. (3 mm), adjust the height adjustment rod on the high side to level the deck.
3. Check the front-to-rear level. **Rotate the center blade to point forward.** Measure the distance from blade tip to ground on the front and rear. The rear of the blade should be 1/8 to 1/4 in. (3 to 6 mm) higher than the front of the blade; remove the chain from the deck height adjuster clevis and adjust equally to achieve **at least** 1/8 in. (3 mm) difference. Reinstall chains.

NOTE: The mower deck and support frame are jig welded; within normal tolerances, very little, if any, adjustments should be required to level the deck. Tire pressure will influence the levelness of the deck. Check the tire pressure as a possible cause of the deck not being level.



Deck Leveling

Assembly Instructions

PREOPERATING CHECKLIST

Before operating the mower for the first time, and as a routine before daily operations, it is important to make sure the mower is properly prepared and ready for operation. The following is a list of items to be checked. (For a mower with frequent operation, some of these items will not need to be checked every day, but the operator should be aware of the condition of each.)

For proper fuel and lubricants refer to **Specifications**.

☐ FILL FUEL TANK(S)

Fill the fuel tank(s) using clean, fresh, automotive grade **unleaded** gasoline (87 octane rating minimum) or gasohol (up to 10% ethyl alcohol, 90% unleaded gasoline by volume). See engine manual for complete fuel recommendations.



DANGER

Handle gasoline with care. Gasoline is highly flammable and its vapors are explosive. Use safe refueling procedures:

- **DO NOT** fill fuel tank(s) with the engine running.
- If the engine is hot, allow to cool before refueling.
- Use an approved fuel container.
- Fuel the mower outdoors.
- **DO NOT** smoke while refueling.
- Avoid spilling fuel; use a funnel or spout.
- **DO NOT** overfill the fuel tank(s); fill up to about 1 in. (25 mm) below the top of tank.

IMPORTANT: DO NOT permit dirt or other foreign matter to enter the fuel tanks. Wipe dirt from around the filler cap(s) before removing. Use a clean fuel storage container and funnel.

IMPORTANT: DO NOT mix oil with gasoline. Always use fresh, automotive grade unleaded gasoline or gasohol. **DO NOT** use premium, white, or high-test gasoline. **DO NOT** use additives, such as carburetor cleaners, deicers, or moisture removing agents. **DO NOT** use gasoline blended with methyl alcohol.

☐ CHECK ENGINE CRANKCASE OIL LEVEL

Check the engine crankcase oil level before use and **after each 8 hours** of continuous operation. Refer to **LUBRICATION** for *Checking Engine Crankcase Oil Level* in **Maintenance Instructions**.

☐ CHECK AND SERVICE ENGINE AIR CLEANER SYSTEM

- Check air restriction gauge to make sure there is no red indication showing.
- Check condition, cleanliness, and security of the complete air cleaner system (inspect air filter **every 100 hours**). For detailed procedures, refer to **CLEANING** the **Engine Air Cleaner System** in **Maintenance Instructions**.

☐ CHECK ENGINE COOLING SYSTEM

Check that the engine cooling air intake screen is free of obstruction by grass clippings or debris and clean if required. Also, cylinder head cooling fins should be inspected and cleaned if any build-up of debris is noted [remove two (2) cylinder head access panels to inspect and clean].

Check performance of the cooling system by starting the engine, holding a hand adjacent to the cylinder heads, and feeling the cooling airflow.



DANGER

Make sure to keep hands clear of exhaust pipe, muffler, and moving parts when checking airflow.

☐ CHECK SECURITY OF DRIVE TIRE MOUNTING NUTS

The eight (8) Drive Tire mounting nuts should each be torqued to 75 to 85 ft-lbs. (101.7 to 115.2 N·m).

☐ INSPECT FOUR (4) DRIVE BELTS

Engine/PTO and Ground Drive.

☐ CHECK HYDROSTATIC TRANSAXLE OIL LEVEL

Refer to **LUBRICATION** for **Transaxle Lubrication** in **Maintenance Instructions**.

Assembly Instructions

☐ CHECK TIRE PRESSURE

Deck Caster Wheel = 20 PSI (137 kPa)

Drive = 15 PSI (103 kPa)

Rear = 20 PSI (137 kPa)

☐ CHECK FUNCTION OF SAFETY INTERLOCK SWITCHES

Refer to **Operating Instructions** to check for proper operation of safety switches, both during engine starting and with the operator leaving the seat with tractor moving forward or with mower blades engaged.


☐ CHECK AND CLEAN GRASS BUILDUP UNDERNEATH MOWER DECK

Refer to **CLEANING the Grass Buildup in Mower Housing** in **Maintenance Instructions** for deck tilt-up and deck cleaning information.

DANGER

Never operate cutter blades with deck in raised position because it is hazardous.

The tilt-up deck can be secured in the raised position by disengaging the locking arms on each side of the carrier frame and inserting the deck hook into the tilt-up latch on the tractor body. Before operating the tractor, make sure to re-engage the locking arms after lowering the deck to the normal operating position.



Deck Secured in Tilt-Up Position

CAUTION

Do not operate machine with locking arms disengaged.

DANGER

Do not operate the mower with deck in tilt-up position. Do not move the tractor with the deck in the tilt-up position.

☐ CHECK MOWER BLADE CONDITION, SHARPNESS, BALANCE, AND SECURITY OF MOUNTING

The blade mounting bolt should be tightened to 64 ft-lb (86.8 N·m). If blade sharpening is required, refer to **CHECKING/SERVICING for Sharpen Mower Blades** in **Maintenance Instructions**.

☐ ADJUST MOWER CUTTING HEIGHT, IF REQUIRED

Refer to **ADJUSTING CUTTING HEIGHT** in **Operating Instructions**.

☐ PERFORM ANY ADDITIONAL PROCEDURES called for on the **MAINTENANCE SCHEDULE CHART** in **Maintenance Instructions**.

Operating Instructions

CONTROL IDENTIFICATION, LOCATION, AND FUNCTION


CAUTION

Before operating the mower, become familiar with the location and function of all operator controls. Knowing the location, function, and operation of these controls is important for safe and efficient operation of the mower.


Ignition Switch

The ignition switch is located on the right front of the body and is used to start and stop the engine. The switch has three positions: "O" is the **OFF** position, **RUN** is the position the key returns to after starting, and "S" is the **START** position. When starting the engine, turn the key clockwise to the "S" position. Do not hold the key in the "S" position longer than 10

seconds. If the engine does not start, return the key to the "O" position for at least 60 seconds before making a restart attempt. Prolonged cranking can damage the starter motor and shorten battery life. Release the key when the engine starts, and it will return to the **RUN** position. To stop the engine, rotate the key counterclockwise to the "O" position.



Ignition Switch



Operating Controls

Operating Instructions


Engine Choke (Model MBS Only)

The choke control lever (black knob) is located on the left side of the seat. To start a cold engine, move the choke control forward to the **ON** position. After engine starts, move choke control toward the **OFF** position, keeping enough choke to allow the engine to run smoothly as it warms up. As soon as possible, move the choke to the **OFF** position. A warm engine requires little or no choke for starting.

IMPORTANT: Make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.

Engine Throttle

The throttle control lever (red knob) is located on the left side of the seat and is used to control engine speed. Moving the lever **forward** toward the **FAST** position **increases** engine speed; moving it **backward** toward the **IDLE** position **decreases** engine speed.



Choke and Throttle Location

Body Latch

The front portion of the tractor body hinges forward for maintenance access and is latched down in the **OPERATING** position. To raise the body, move the latch release forward.



Body Latch

Forward Speed Control (FSC)

Forward Speed Control (FSC) has two functions: One is to set forward travel speed, and the other is to establish the **NEUTRAL-PARK** position. When the FSC lever is moved into the **FORWARD** position, a friction lock holds any forward speed setting from 0 to 9 mph (0 to 14 km/h). The ground speed is proportional to the lever position; the further the lever is advanced forward, the faster the tractor moves. It is not necessary to hold the FSC in position since the friction lock maintains the selected lever position. Pulling back on the steering levers overrides the FSC setting and slows or stops forward travel. Releasing the steering levers allows the tractor to resume forward travel at the speed set by the FSC lever. To stop and park the machine, the FSC lever is moved backward to the **NEUTRAL-PARK** position.

Operating Instructions

Steering Levers

Each drive wheel is controlled by its own independent steering lever, for both steering function and **FORWARD/REVERSE** motion. The FSC lever sets the maximum forward speed, and also sets the forward position of the steering levers. The steering levers operate **only with a backward pulling** movement of the lever, which causes the drive wheel for that lever to first slow down, stop, and then reverse with a full backward lever stroke. The levers are released to the **FORWARD** position for “straight-ahead” ground travel.

NOTE: Pushing forward on the steering levers will not cause **any** change in tractor motion - there will be no steering lever reaction and there will be no machine damage.

Blade Clutch (PTO)

The blade clutch lever has two positions. Pulling the lever **FORWARD engages** the PTO that drives the mower blades. Pulling the lever **BACKWARD disengages** the PTO and engages the blade brake.

Parking Brake

The parking brake functions by locking a detent arm internally into the transaxle. Moving the lever **FORWARD engages** the parking brake; moving the lever **BACKWARD releases** the brake.

IMPORTANT: Stop the tractor completely before engaging the parking brake. The parking brake uses a positive mechanical lock similar to the **PARK** position on an automotive automatic transmission. If the tractor is moving when the brake is engaged, it will result in sudden stoppage and possible internal damage to the transaxle.

NOTE: If pressure on the parking brake pin (e.g. parked on a hill) makes it impossible to release the parking brake with the parking brake lever, move the mower gently forward or backward to allow the brake detent to release.



Parking Brake Engaged



Parking Brake Disengaged

Operating Instructions

Oil Pressure Warning Light

The oil pressure warning light indicates that engine oil pressure is below the safe operating level [below 3 to 5 PSI (21 to 34 kPa)]. This **light (and warning horn)** will come on when the ignition is turned **ON**, but should go off after the engine is started. If the light fails to come on when the ignition switch is turned **ON**, it could indicate a burned out bulb. If the light comes on during engine operation, stop the engine immediately and correct the source of the problem before further engine operation.

IMPORTANT: Continued operation of the engine with an illuminated oil pressure warning light **MAY** cause severe engine damage (if a low oil pressure condition exists).

Engine Service Light (Model MBS26 Only)

The engine service light indicates the Engine Control Unit (ECU) has detected a fault in the engine performance. When this light illuminates during operation, contact an authorized Kohler Service dealer to diagnose the fault.

IMPORTANT: Continued operation of the engine with an illuminated engine service light will result in sub-standard performance and **MAY** cause engine damage if not corrected as soon as possible.


Over Temperature Warning Light

The over temperature warning light indicates that engine oil temperature and/or cylinder head temperature are above the safe operating limit and the **engine is overheating** [above 305° F (152° C) oil or 450° F (232° C) cylinder head]. If this light comes on, there may be a problem with:

- Engine cooling system (material packed into cylinder head cooling fins, clogged air intake screen)
- Low oil level in crankcase

Stop the engine and correct the source of the problem before further operation.

IMPORTANT: Continued operation of the engine with an illuminated over temperature warning light **MAY** cause severe engine damage (if a high oil temperature or head temperature condition exists).




Engine Warning Lights

Operating Instructions

Transaxle Lockout Rods

The transaxle lockout rods disengage the transaxles. By **lifting** the rods up and locking them into place with the shoulder on the rod in the chassis notch, the transaxles are released to permit freewheeling. By releasing the rods and **recessing** them back toward the chassis, the transaxles are engaged for normal operation. The transaxle rods in the **LOCKOUT** position are used to enable moving the machine without the engine running (e.g., for service). Refer to **TRANS-AXLE LOCKOUTS** in this section for operating instructions.

NOTE: The transaxle lockout rods ends should be completely retracted against the chassis, otherwise operation of the transaxle may be erratic.



Hydro Lockout Rod Location

Hourmeter

The hourmeter, which is located on the right front of the body, displays **operating time** accumulated while the ignition switch is in the **ON** position.

The hourmeter provides maintenance reminders after certain hours of operation. The hourmeter screen will start flashing the reminder one hour prior to the recommended interval and will continue until one hour after the recommended interval (two hours). The hourmeter **does not have a manual reset function**.


Procedure	Interval*	Reminder
Oil Change (Break-In)**	4-6 Hours	C H G OIL
Lubricate and Check Levels	24-26 Hours	LUBE
Oil Change	49-51 Hours***	C H G OIL

* These intervals reflect the actual time that the reminder will flash (one hour prior to and one hour after the recommended interval).

** This reminder is only used one time.


*** In normal operating conditions, oil changes in 100-hour intervals are acceptable. Walker and the engine manufacturers recommend engine oil changes every 50 hours in extremely dirty or dusty conditions or for units with less than 100 hours annual use.

NOTE: The blinking hour glass on the display means that the meter is operating properly.



Hourmeter

Operating Instructions



Operating Instructions

STARTING THE ENGINE



CAUTION

Before operating the mower, read and understand all Safety Instructions and Operating Instructions.



WARNING

NEVER run the engine in an enclosed or poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.

1. Before attempting to start the engine, make sure the operator is in the seat, the Forward Speed Control is in **NEUTRAL-PARK** position, and the blade clutch and parking brake are **DISENGAGED**.

NOTE: Release parking brake to prevent extra load on the starter if the transmission neutral is slightly out of adjustment.



CAUTION

A safety interlock switch system **PREVENTS CRANKING** the engine with either the Forward Speed Control or the blade clutch (PTO) out of neutral. If the engine cranks otherwise, the safety system is not working and should be repaired or adjusted before operating the mower. **DO NOT** disconnect safety switches; they are for the operator's protection.

2. Move the choke lever to the **ON** position (for MBS models) and move the throttle 1/4 to 1/2 open (toward **FAST**). Turn the ignition switch to the **START** position to start the engine. Release the key to **RUN** position as soon as the engine starts.

NOTE: For MBS models the choke may not be required if the engine is warm.

IMPORTANT: DO NOT crank the engine continuously for more than 10 seconds at a time. If the engine does not start, turn the key to the **OFF** position and allow a 60 second cool-down period between starting attempts. Failure to follow these guidelines can damage the starter motor and shorten battery life. Contact your Walker dealer or authorized Kohler dealer for additional help.

3. After the engine starts, gradually move the choke to the **OFF** position, keeping enough choke on to allow the engine to run smoothly as it warms up. As soon as possible, move the choke to the **OFF** position (for MBS models).

IMPORTANT: For MBS models make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.

ADJUSTING GROUND SPEED AND STEERING



CAUTION

Learn to **START, STOP, and MANEUVER** the mower in a large, open area.

If the operator has not operated a machine with **LEVER STEERING OR DUAL TRANSAXLES**, steering and ground operation should be learned and practiced until the operator is completely comfortable handling the machine **BEFORE ATTEMPTING TO MOW**.



DANGER

Keep feet on footrest at all times when the machine is moving. **Never** operate the tractor without a deck or implement installed.

Operating Instructions

Beginning Recommendations are:

- ◆ Learn operation of the mower in an open area away from buildings, fences, and obstructions. Learn operation on flat ground **BEFORE** operating on slopes.
- ◆ Start maneuvering the mower with **SLOW** engine speed and **SLOW Forward Speed Control** setting until familiar with all operating characteristics.
- ◆ Remember it is not necessary to hold the steering levers forward (a unique Walker feature); always **PULL** on the levers for steering or for reverse motion of the mower.
- ◆ Learn to operate the mower with your left hand on the steering levers and right hand on **Forward Speed Control**. The use of two hands on the steering levers tends to cause over-control.
- ◆ Learn to operate the steering levers with smooth action. Jerky movements are hard on the transmission and lawn. For sharp turns, do not allow the inside wheel to stop and twist on the grass. Pull the steering lever controlling the inside wheel into reverse for a smooth “rolling” turn (one wheel rolling forward while the other rolls backward).
- ◆ Practice maneuvering the mower until you can make it go exactly where you are aiming.
- ◆ Remember, for an emergency stop, or in case of loss of control, machine movement can always be stopped quickly by pulling the **Forward Speed Control** into the **NEUTRAL-PARK** position.

1. Move the FSC out of **NEUTRAL-PARK** position to the desired forward speed. **DO NOT** hold forward on steering levers. It is not necessary to hold the FSC lever in position since a friction lock maintains the selected lever position (and forward travel speed).



WARNING

In case the transmission drive belt breaks during operation, and if the machine is on a slope, the machine will freewheel down the slope. To maintain control, immediately (1) Release the steering levers and simultaneously (2) Move the FSC to the **NEUTRAL-PARK** position. When the machine is stopped or moving slowly, engage the parking brake.

NOTE: This is exactly the same procedure used to normally stop and park the machine.

NOTE: If the FSC lever will not stay in the selected position, the friction lock needs to be adjusted. Contact your Walker dealer.



CAUTION

A safety interlock switch (seat switch) will cause the engine to stop if the FSC is out of the **NEUTRAL-PARK** position and the operator is not in the seat. The function of this switch should be checked by the operator raising off the seat with the tractor moving forward (allow 1 to 1-1/2 seconds off the seat for the time delay function); the engine should stop. If the safety system is not working, it should be repaired or replaced before operating the mower. **DO NOT** disconnect the safety switches; they are for the operator's protection.

2. Steer by pulling the lever on the side of desired direction of turn, e.g., pull the **LH** lever to **turn left**. To minimize the possibility of overcontrol, use only one hand on both steering levers.

Operating Instructions



Correct Operator Hand Position on the Controls

- Reverse direction of the mower by pulling both levers backward.

NOTE: Smooth action on the steering levers will produce smooth mower operation. Remember to keep the engine and ground speed slow until learning the control response.

- The FSC may be adjusted forward for faster ground speed and backward for slower ground speed. When mowing, ground speed should be adjusted to match the load on the cutter blades, i.e., as the engine pulls down in heavy cutting, pull back on the FSC lever to reduce ground speed. Adjusting ground speed helps maintain a balance between engine power and blade speed for high-quality cutting action.
- Stop ground travel by pulling both steering levers backward to the **NEUTRAL-PARK** position (tractor not moving) and then moving the FSC lever to the **NEUTRAL-PARK** position.

NOTE: If the tractor creeps forward or backward with the FSC lever in the **NEUTRAL-PARK** position, the transmission control needs to be adjusted. Contact your Walker dealer.

ENGAGING THE MOWER

- Set the engine throttle at about 1/3 speed. **Do not attempt to engage the blade clutch at high engine speeds.** This will drastically shorten drive belt life. Use only moderate engine speed when engaging the blade clutch.
- Engage the mechanical clutch by pulling the blade clutch lever forward **quickly**. **DO NOT** engage slowly. For disengagement, push the blade clutch lever backward **quickly**.

CAUTION


A safety interlock switch (seat switch) will cause the engine to stop if the blade clutch is engaged and the operator is not in the seat. The function of this switch should be checked by the operator raising off the seat and engaging the blade clutch; the engine should stop. If the switch is not working, it should be repaired or replaced before operating the mower. **DO NOT** disconnect the safety switches; they are for the operator's protection.

IMPORTANT: DO NOT engage the blade clutch when transporting the mower across drives, sidewalks, loose materials, etc. **DO NOT engage the blade clutch with the PTO shaft disconnected** (the mower deck removed from tractor).



Blade Clutch Engaged

Operating Instructions



Blade Clutch Disengaged

CAUTION

If the cutting blades strike a stationary object while mowing, stop the mower immediately, disconnect the spark plug wires, lift the deck, and inspect the deck and blades thoroughly for damage. Also, make sure the blade retaining bolts are torqued to 64 ft-lb (86.8 N·m).

STOPPING THE MACHINE

1. Pull the steering levers to the **NEUTRAL-PARK** position and then move the FSC lever backward to the **NEUTRAL-PARK** position.
2. Slow the engine to idle; put the throttle in the **IDLE** position.
3. Disengage the blade clutch.

IMPORTANT: DO NOT disengage the blade clutch with high engine speed (above 1/2 throttle) since the brake action on the blade drive will cause premature wear of the Engine/PTO Belt and internal braking mechanism (or system).

WARNING

A brake stops the cutter blades from free-wheeling within five (5) seconds after disengaging the clutch. If the brake system malfunctions and the blades do not stop within five (5) seconds, the brake should be repaired or replaced before operating the mower. Contact your Walker dealer.

4. Turn the ignition switch **OFF**.

WARNING

Remove the key from the ignition switch when leaving the mower unattended. This will prevent children and inexperienced operators from starting the engine.

5. Engage the parking brake. Also, engaging the parking brake is recommended when stopping or parking the machine in a confined space with little tolerance for movement.

IMPORTANT: The transaxles lock to prevent the mower from rolling freely with the engine stopped. However, if the mower is parked on a slope, it is necessary to **ENGAGE** the parking **BRAKE** to prevent the mower from creeping. This is due to a small amount of slippage in the transaxles, especially when transmission fluid is warm.

WARNING

In case either of the transmission drive belts break during operation, and if the machine is on a slope, the machine will freewheel down the slope. To maintain control, immediately (1) Release the steering levers and simultaneously (2) Move the FSC to the **NEUTRAL-PARK** position. When the machine is stopped or moving slowly, engage the parking brake.

NOTE: The emergency stop procedure is exactly the same procedure as used to normally stop and park the machine.

Operating Instructions

FUEL SELECTOR VALVE

The tractor is equipped with dual fuel tanks. A fuel selector valve regulates which tank is being utilized. On the Model MBS26 the valve is located on the left hand side of the engine. On the Model MBS the valve is located on the right hand side of the engine. The valve switches between the LH and RH gas tanks. **DO NOT** run tank dry before switching tanks.



Fuel Selector Valve - Model MBS26



Fuel Selector Valve - Model MBS

ADJUSTING CUTTING HEIGHT



WARNING

Never adjust cutting height while the mower is moving. Before adjusting cutting height or servicing, move the Forward Speed Control (FSC) into the NEUTRAL-PARK position, engage the parking brake, and disengage the blade clutch (PTO). Tractor should not be moving while adjusting cutting height.

Cutting height is adjusted from operators seat using the height pedal to assist in raising the deck while positioning the height adjustment lever and hitch pin.


1. Disengage PTO and stop tractor.
2. Push down on height pedal until it latches in the full up position.
3. Select desired height by moving the hitch pin to the desired height.
4. Push down on the height pedal and lift up on the height adjustment lever. Slowly release the height pedal while lifting the lever until there is no pressure on the pedal.



Cutting Height Adjustment

Transport Position

1. Disengage the PTO.
2. Push down on height pedal until it latches in the full up position.



Cutting Height Adjustment Components


Operating Instructions

TRANSAXLE LOCKOUTS

IMPORTANT: DO NOT TOW this mower with the transmission lockout engaged. Towing can produce excessive internal pressure and damage the transaxle(s).


To move the mower with the engine **NOT** running (dead battery, maintenance, etc.), the transaxles are unlocked (released).

1. Raise the body.
2. Pull up the transaxle lockout rods on both the RH and LH transaxles and secure into place by shouldering both rods in the chassis notch area.
3. The mower will "freewheel" with the rods in the **LOCKOUT** position. The levers must be in the highest position to completely unlock the transmissions.



Hydro Lockout Rod - Freewheel Position

4. After moving the mower, release the rods, placing them in the normal **OPERATING** position. The transmission rod ends should be completely retracted against the chassis, otherwise operation of the transmission may be erratic.




Hydro Lockout Rod - Normal Operating Position

RECOMMENDATIONS FOR MOWING



Do not mow around overhanging tree branches or bushes at the same height as the operator's torso and head where inadvertent contact may cause injury.



Avoid Low Hanging Branches

IMPORTANT: Operate the engine at **full throttle** when mowing, to allow the engine to produce full horsepower and to increase efficiency of the engine cooling system.

- Keep the mower deck clean.
- Mow with **sharp blades**. A dull blade tears the grass (resulting in poor lawn appearance) and uses extra power (slowing the mowing speed).
- It is preferable to cut grass when it is **dry** and **not too tall**. Mow frequently and do not cut grass too short. (For best appearance, cut off 1/3 or less of existing grass height.)

Operating Instructions

- When mowing, operate the engine at or near **full throttle** for the best cutting action. Mowing with a lower engine RPM causes the mowing blade to not cut clean and tear the grass. The engine is **designed to be operated at full speed**.

- When mowing in adverse conditions (tall and/or wet grass), mow the grass twice. Raise the mower to the highest setting - 5 in. (127 mm) - for the first pass and then make a second pass cutting to the desired height.


- Use a **slow** setting on the FSC for **trimming** operations.

- Make sure the mower is **leveled properly** for a smooth cut. Refer to *Deck Leveling in Assembly Instructions*.

- Use an alternating **stripe mowing pattern** for **best appearance** and vary the direction of the stripe each time the grass is mowed to avoid wear patterns in the grass.


- Avoid damage to the grass by slipping and skidding of the drive tires. Use **smooth control movements** of the steering levers since the transaxles are "power boosted controls" and jerking the levers can easily slip the tires. For sharp turns, do not allow the inside wheel to stop and twist on grass; pull inside steering lever into reverse for a smooth "rolling" turn (one wheel rolling forward while the other rolls backward).

- For DSD60 models, the side discharge shield **must not be removed** and must be kept in the lowest possible position to deflect grass clippings and thrown objects downward. Orient the side discharge away from sidewalks or streets to minimize cleanup of clippings. When mowing close to obstacles, orient the side discharge away from obstacles to reduce the chance of damage to property by thrown objects.



Side Discharge Shield in Lowest Position

- When operating on a slope, **reduce speed and use caution** to start, stop, and maneuver. Avoid sharp turns or sudden changes in direction. The **maximum recommended side slope operating angle is 20 degrees or 33% grade**.



Maximum Recommended Side Slope

Operating Instructions

DANGER

Do not mow or dump grass within 5 feet (1.5 meters) of an embankment or retaining wall with drop off.

RECOMMENDATIONS FOR TILT-UP DECK OPERATION/TRANSPORT

To avoid potential deck and/or tractor damage while using the tilt-up deck, the following recommendations are offered:

- **Do not move the tractor** with the deck in the tilt-up position since both the roller wheels (on the back of the deck) may be damaged by moving the tractor. The tilt-up configuration should only be used when the tractor is parked.
- The tractor **body should never be tilted forward** with the deck in the tilt-up position. This can cause the deck to unhook from the tractor and fall with considerable force, potentially causing deck or tractor damage and/or bodily injury.
- When transporting a tractor with the deck in the tilt-up position (on a truck or trailer), the **deck should be secured** to the vehicle with a strap or rope (stop vertical movement). This will prevent the deck from bouncing on the rear roller wheels (causing breakage). This will also prevent the deck from unhooking from the tractor and falling, potentially causing deck or tractor damage. Damage to other items parked in front of the deck may also occur.



No Driving Zone

Maintenance Instructions



CAUTION

Maintenance procedures requiring special training or tools should be performed by a trained technician.

MAINTENANCE SCHEDULE CHART - RECOMMENDED SERVICE INTERVALS - MODEL MBS26 AND MBS

Service Item	Daily	25 Hours	100 Hours	200 Hours	400 Hours	Yearly	Every 2 Years	Ref. Page
Check Engine Crankcase Oil Level	x							40
Check/Clean Engine Air Cooling System*	x							48
Check Air Filter Restriction Gauge	x							46
Clean Grass Buildup Under Deck	x							49
Service Mower Blades	x							53
Check Security of Air Filtration Components	x							52
Lubricate Grease Fittings and Oil Points*		x						43
Check Transaxle Fluid		x						42
Check Tire Pressure		x						53
Check Drive Belts (Engine/PTO, Ground Drive)		x						56
Check Safety System		x						55
Check Battery Electrolyte Level		x						52
Change Engine Crankcase Oil**			x ^Δ					40
Check Air Filter Element ***			x					47
Clean Engine Cooling Fins			x					48
Check Security of Drive Tire Mounting Nuts (75 to 85 ft-lbs.)			x					22
Clean Transaxle Cooling Fins			x					51
Check FSC Friction Lock			x					55
Check Blade Brake Action			x					55
Change Engine Oil Filter				x				40
Check/Regap Spark Plugs				x				54
Change Transaxle Oil and Filter					x ^{ΔΔ}			42
Check Fuel Lines and Clamps						x		54
Replace Air Filter Element and Dust Ejection Valve ***						x		47
Service Battery						x		52
Replace Fuel Filter						x		59
Service Solenoid Shift Starter						x		ΔΔΔ
Check PTO U-Joints for Wear/Looseness						x		55
Replace Fuel Lines and Clamps							x	54

* More often in extremely dusty or dirty conditions (Refer to notes about air cleaner element under IMPORTANT TIPS FOR CARE OF KOHLER ENGINE)

** Change engine oil and filter after first 8 hours of operation of a new engine (break-in period)

*** Air cleaner is remote mounted Cummins/Fleetguard OptiAir™ unit, replace filter every year

Δ Change oil every 50 hours when operating in dry, dirty conditions

ΔΔ Initial oil and filter change at 75-100 hours

ΔΔΔ See your Walker dealer for this service or refer to the Walker Service Manual



CAUTION

When performing maintenance with the mower body raised, a safety prop should be installed from back of body to chassis frame (fail-safe protection in case of failure of body lift support).

IMPORTANT TIPS FOR CARE OF THE KOHLER ENGINE

Fuel System

- Fuel must be clean - free from water, dirt, and organic material.
- Change fuel filter on a regular basis and when contamination is suspected or found in the fuel.
- On the Model MBS26, the fuel system is pressurized. Do not attempt to service this fuel system. Contact your Walker dealer or authorized Kohler service dealer for work on the fuel system.

Starting/Stopping

- Start engine with the throttle advanced off idle (1/4 to 1/2 throttle). This will aid starting, especially in cold weather.
- Keep the battery fully charged.
- Match crankcase oil viscosity to the ambient temperature, allowing the engine to crank faster and start easier.
- Position the throttle control between half and full throttle, then stop the engine.

Cooling System



DO NOT use a pressure washer to clean the cooling system on an air-cooled engine, mud may form under the cooling shroud on the cylinder head and cooling fan.

- Keep engine air intake screen and cylinder head fins free of grass clippings, chaff, and dirt. Inspect intake screen and cooling fins for cleanliness and no damage.
- Periodically remove two access panels in the engine shroud to inspect and clean cylinder head cooling fins.
- Check performance of the cooling system by starting the engine, holding a hand adjacent to the cylinder head, and feeling the cooling airflow.



Make sure to keep hands clear of exhaust pipe, muffler, and moving parts when checking airflow.

- Operate the engine at full speed when mowing. This allows the engine to produce full horsepower and move more cooling air through the engine cooling fins.

Air Cleaner System

- Use **only** Cummins/Fleetguard air cleaner elements. Aftermarket elements may not seal in the air cleaner housing, allowing dirt to enter the engine. Also, aftermarket filters often skimp on the filtration media and require more frequent replacement (see following instructions).
- Use the air flow restriction gauge to indicate the need to service the air filter.
- **DO NOT overservice** or frequently “disturb” the **air filter**. A dirty air filter actually cleans better than a new one. Changing the air filter too often can actually reduce filter efficiency and increase the opportunity for traces of dust to enter the engine. Wait until the element really needs servicing as indicated by the air flow restriction gauge.
- When the air filter element is removed or replaced, make sure all **dust is cleaned out** of the **air cleaner housing and hose**. Use a damp cloth and wipe the interior of the canister and hose clean (a little dirt left here will be sucked into the engine and reduce engine life). When the filter is reinstalled, make sure the **element is held tight and straight** in the canister for proper seating and sealing.
- Periodically check the air intake hose for cuts, nicks, etc., and the hose clamps for tightness.

Oil

- Use only multi-viscosity oils as specified with the viscosity matching ambient temperatures for the engine operating conditions. This will **aid starting** in cold weather and assure proper lubrication in hot weather.
- Use only Kohler oil filters. **Aftermarket filters may not seal properly** and/or have the incorrect pressure relief valve for proper lubrication.

LUBRICATION



WARNING

DO NOT attempt to lubricate the machine with the engine running. Disengage the PTO clutch, shut off the machine, and remove the ignition key.

Proper lubrication is an important maintenance procedure. It reduces wear and makes the machine quieter and easier to operate.

Engine Oil

Engine Break-In Oil

No special break-in oil is required. The engine is serviced with 10W-30, Service Class SG oil from the factory. The oil should be changed after the initial engine **break-in period of 5-8 hours**. Thereafter, change oil **after every 100 hours** of operation.

Checking Engine Crankcase Oil Level

Check the engine crankcase oil level before use and **after each 8 hours** of continuous operation.


IMPORTANT: The importance of checking and maintaining the proper crankcase oil level cannot be over-emphasized. Check the oil level **BEFORE EACH USE**.

1. Park the mower on a **level surface with the engine stopped**. Also, make sure the engine is cool and oil has had time to drain into the sump [allow **at least five (5) minutes** after stopping the engine].

IMPORTANT: **NEVER** check or add oil with the engine running.

2. Before removing the dipstick, clean the area around the dipstick to keep any dirt or debris out of the engine.
3. Remove the dipstick, wipe off with a clean rag, then reinsert the dipstick into the tube and tighten.
4. Remove the dipstick again and check the oil level on the dipstick. The oil level should be within the "Operating Range" on the dipstick (between the **LOW** mark and the **FULL** mark).

IMPORTANT: **DO NOT** operate engine without sufficient oil supply in the crankcase. **DO NOT** operate with oil level below the **LOW** mark or above the **FULL** mark on the dipstick.



Dipstick Operating Range

5. If additional oil is needed, refer to **Specifications** for proper crankcase lubricant. **Fill to the FULL mark.**

IMPORTANT: **DO NOT** overfill crankcase (oil above **FULL** level) as this **CAN** result in engine overheating, loss of power, and possible engine damage.

Changing Engine Crankcase Oil/Oil Filter


Change the engine crankcase oil **after every 100 hours** of operation and the oil filter **after every 200 hours** of operation as follows:

1. Park the mower on a **level surface with the engine stopped**. The engine oil should be warm before draining. If not warm from operation, start the engine and run a few minutes to warm the oil.
2. Before removing the dipstick, clean the area around it to keep any dirt or debris out of the engine.

3. Remove the dipstick and oil drain plug, and drain oil into a suitable container. Be sure to allow ample time for complete drainage.
4. Before removing the oil filter, clean the area around the filter to keep dirt and debris out of the engine.
5. Remove the old oil filter and wipe off the filter mounting surface on the engine.



Dipstick and Oil Fill
(View from Above Left Side of Tractor)



Oil Drain and Oil Filter Locations
(View from Above Right Side of Tractor)

6. Apply a thin coating of new oil to the rubber gasket on the replacement oil filter.

IMPORTANT: Use **ONLY** oil filters from the engine manufacturer. Aftermarket oil filters may not seal properly and/or may not have the correct pressure relief valve for proper lubrication.

7. Install the new oil filter on the engine. Turn the oil filter clockwise until the rubber gasket contacts the sealing surface, then tighten the filter an additional **1/2 to 3/4 turn**.
8. Reinstall the drain plug.
9. Fill the crankcase with new, clean oil. Use only crankcase lubricants recommended by the engine manufacturer. Refer to **Specifications** in this manual or the engine owner's manual. Use the recommended oil viscosity for the expected ambient temperature. Oil with the correct viscosity will aid starting in cold weather and assure proper lubrication in hot weather. **Fill to FULL mark** on the dipstick; crankcase capacity is 1.9 quarts (1.8 liters) when changing oil and filter.

IMPORTANT: Check the dipstick reading before pouring in the last 1/2 pint of oil and **fill only to the FULL mark**. The oil level should never be over the **FULL** mark on the dipstick; overfilling can result in engine overheating and loss of power.

10. Start the engine and check for oil leaks around the oil filter. Stop the engine, recheck the oil level, and add oil if necessary. (When the engine is first operated with a new oil filter, the oil level will drop slightly as the filter is filled with oil.)

Mower Deck Spindle Lubrication


These spindles are permanently sealed and require no lubrication.

DRD52 or DSD60 Mower Deck Lubrication

Lubricate the U-Joint in the drive shaft **every 8 hours** with SAE general purpose lithium or molybdenum base grease.

Transaxle Lubrication

- The transaxle oil lubrication is SAE 20W-50 (API Service Class SL or higher) engine oil.
- Inspect both transaxle cases and hoses **after every 100 hours** of operation for visible leaks.
- The fluid levels for each transaxle can be checked visually by looking at the fluid levels in each expansion reservoir. When the transaxles are cold, the fluid level in the expansion reservoirs should be between 1/4 and 1/2 in. (0.64 cm and 1.27 cm).




Expansion Reservoir Location

Transaxle Oil and Filter Change

Change the transaxle oil after the initial **break-in period of 75-100 hours**. Thereafter, change oil **every 400 hours** of operation as follows:

1. Thoroughly clean the exterior of the transmission housing before servicing. Using a 1/4 in. hex wrench, remove the plug on the lower inside of each transaxle allowing the oil to drain.
2. Remove and replace the oil filters using a 3/8 in. hex wrench. (Refer to **Transaxle Oil Drain Plug, Filter, and Guard Location** illustration.)



Transaxle Oil Drain Plug, Filter, and Guard Location
(Shown with Deck Support Arms Removed for Clarity)

3. Reinstall drain plugs.
4. Remove the oil reservoir hose attached to the elbow on top of the transaxles and remove the elbows to access the oil fill openings.
5. Fill the transaxles with 20W-50 (API Service Class SL or higher) oil through the opening where the elbows were. Fill up to the opening.
6. Before reinstalling the elbows, screw the locking nut on the elbows down until they are snug (the o-ring on the elbow will be to the bottom of the o-ring groove).
7. Reinstall the elbows. When the elbow begins to be snug, position the elbow as it was when removed and tighten the locknut.

8. Fill both reservoirs to 1/4-1/2 in. (6-13 mm) with 20W-50 (API Service Class SL or higher) oil.
9. Start and drive the unit for 1- 2 minutes.
10. If the transaxles sound noisy or have poor steering response, recheck oil level in both transaxles by removing the elbows (check oil level at fill opening).
11. If oil needs to be added refer back to steps 4-10.

Grease Fitting and Oil Point Lubrication

Lubricate the grease fittings and oil points after **every 25 hours** of operation. Lubricate **more often** when operating in **dusty or dirty conditions**. Use SAE general purpose lithium or molybdenum base grease for grease fittings and light machine oil (SAE 10) to lubricate oil points. **Lubricate the locations shown in the Chassis and Deck Lubrication Points illustration.**

NOTE: PTO universal joints (on the deck and tractor) require routine lubrication **after every 8 hours** of running time.

NOTE: The best way to lubricate the PTO tube half of the universal joint assembly is to remove it from the tractor. See instructions for removing and installing PTO quick coupler, refer to *Deck Installation* in **Mower Deck Installation on Tractor** in the **Assembly Instructions**.

Maintenance Instructions


LUBRICATION

Ident No.	Location	Lubrication Type	No. Places
1	Deck Caster Wheel Fork Pivot	Grease	2
2	Deck Caster Wheel Bearing	Grease	2
3	Deck Belt Tensioner Pivot	Grease	1
4	Front Deck Lift Pivot	Grease	2
5	Rear Deck Lift Pivot	Grease	2
6	Pivot Assembly, Tilt-Up Deck	Grease	2
7	Deck Support Arm Socket	Grease	2
8	Steering Lever Pivot	Grease	2
9	Deck-to-PTO Coupling (Grease Slide Area)	Grease	1
10	Deck Support Arm Pivot	Grease	2
11	Universal Joint Tube Assembly	Grease*	1
12	Hydro Idler Arm Pivot	Grease	1
13	PTO Belt Tightener Pivot	Grease	1
14	Clutch Actuator Push Rod	Grease	1
15	FSC Lever Pivot	Grease	1
16	Body Latch	Oil	2

Ident No.	Location	Lubrication Type	No. Places
17	PTO Clutch Lever Pivot	Grease	1
18	Clutch Arm Pivot	Grease	1
19	Transaxle Oil Reservoir	Oil	2
20	Throttle Control Cable Ends	Oil	2
21	Choke Control Cable Ends (Model MBS Only)	Oil	2
22	Tail Wheel Caster Fork Pivot	Grease	2
23	Rear Wheel Pivot	Grease	1
24	Rear Wheel Bearing	Grease	2
25	Engine / Oil Filler	Oil**	1
26	Rear Flanged Bearing	Grease	1
27	Parking Brake Pivot	Grease	1
28	Choke Control Pivot (Model MBS Only)	Oil	1
29	Throttle Control Pivot	Oil	1
30	Universal Joint Shaft Assembly	Grease*	1

* Grease every eight (8) hours.

** Refer to **Engine Oil** located on page 40.



Chassis and Deck Lubrication Points

CLEANING



CAUTION


If a pressure washer is used on the exposed working parts, avoid water on the electrical parts and the engine cooling system.

Engine Air Cleaner System

Cummins/Fleetguard OptiAir™ Air Cleaner


A remote mounted Cummins/Fleetguard OptiAir™ air cleaner provides the air filtering function. The paper filter element slides over an outlet tube inside the air cleaner canister with **radial** sealing action, eliminating the possibility of dust leaks due to improper filter installation. Intake design, internal baffling, and a dust ejection valve provide dust separation and automatic precleaning action. Daily or frequent servicing of the air cleaner is **not required**. Use the air restriction gauge on the air cleaner outlet to indicate when the air filter needs servicing -- a red flag will appear when the filter is overly restricting airflow into the engine.

IMPORTANT: Use **only** Cummins/Fleetguard air filter elements for replacement (Walker 2090-1 or 2090-3). Aftermarket filters may not seal properly or filter efficiently.




Air Cleaner Components (Shown with Cover Removed)

IMPORTANT: The Cummins/Fleetguard air cleaner uses a dry paper-type air filter element. **NEVER** apply oil to the paper element.



Engine Air Cleaner System Components



Air Restriction Gauge Location

Inspect the paper element **after every 100 hours** of service and **replace** the element and safety filter **yearly** (or when dirty or damaged). More frequent replacement may be required when operating in extremely dusty conditions as indicated by the air restriction gauge. Service the air cleaner as follows:

1. Lift Mono Latch Twist Lock™ and twist the OptiAir™ cover to the left into the “open” position to remove the air cleaner cover. Wash the cover and dust ejection valve. Check that these components are in good condition. The dust ejection valve is subject to wear and deterioration and should be replaced **yearly** or when damaged. The lips of the valve should close and fit together; any cracks, deformation, or wear in the valve is cause for replacement.
2. Remove the filter element by pulling it out of the canister. There will be some initial resistance as the filter seal breaks loose and slides off of the outlet tube. **Gently** move the end of the filter up and down and side to side or twist to loosen the seal. Use gentle action to minimize the amount of dust dislodged as the filter is removed.
3. Replace the filter element.

NOTE: Washing the element in water or cleaning solution is **not recommended**. Do not try to clean the element with compressed air.


4. Use a bright light inside the element to inspect for damage. Check the element very carefully for **pin holes or other damage** that will allow dirt to leak through the paper media. Replace element if necessary.

5. Without removing, visually inspect the condition of the safety filter for damage or holes. The safety filter should only be removed for yearly replacement (or when dirty or damaged).
6. Check the condition and resilience of the radial sealing surface (inside of the open end) of the filter. Replace the filter if any cracks, tears, or other damage to the sealing surface are noted.
7. Use a clean, damp cloth and wipe the interior of the air cleaner canister clean. Use special care to clean **both the inside and outside** surfaces of the outlet tube.

IMPORTANT: Any dust left on the inside of the outlet tube will go into the engine and cause wear.


8. Check the outside surface of the outlet tube for smoothness and cleanness (this is the sealing surface).
9. Insert and seat the safety filter and OptiAir™ element carefully into the canister, applying pressure at the outer rim of the filter; not at the flexible center. Make sure the filter element is completely in place before installing the cover.

NOTE: DO NOT use petroleum based lubricants on the sealing surfaces of the filter; use talcum powder or dry silicone lubricants if required for filter installation.



Air Filter Element Replacement

10. Install the cover with the word "DOWN" properly oriented to the bottom of the canister. Twist the OptiAir™ cover to the right and put into the "closed" position.



Proper Orientation of Air Cleaner Cover

11. Check the air intake hose for cuts, nicks, cracks, etc., and the hose clamps for tightness.
12. Reset the air restriction indicator (press button on the end of indicator).


Engine Cooling System

Air Intake System

To prevent engine overheating and possible engine damage, clean grass clippings, chaff, and dirt from the rotating engine air intake screen **after every 8 hours of operation**. In certain mowing conditions (dry grass, leaves, tree "cotton", etc.), it may be necessary to check and clean the screen several times each day to prevent engine overheating.

CAUTION

Operating the engine with a blocked air intake screen, dirty or plugged cooling fins, and/or cooling shrouds removed will cause engine damage from overheating.



Keep Engine Screen Clean

Cylinder Head Cooling Fins

It is essential for performance and longevity of the air-cooled engine to keep the cylinder head cooling fins clean and free of obstruction. After **every 8 hours** of operation, check the performance of the cooling system by starting the engine, holding a hand adjacent to the cylinder head, and feeling the cooling airflow. If there is little or no airflow, clean the cooling fins as described on the next page.


DANGER

Make sure to keep hands clear of exhaust pipe, muffler, and moving parts when checking airflow.



Cooling System Airflow

Every 100 hours, inspect and clean the cooling fins (more often when operating in extremely dusty, dirty conditions). Remove the two (2) cooling fin access panels in the engine shroud and clean the cooling fins and external surfaces using compressed air. Make sure to reinstall the access panels before operating the engine.



**Engine Air Intake Screen
and Cooling Fin Access Panels**


Grass Buildup in Mower Housing



DANGER

Before raising or removing the mower deck for cleaning, stop the engine, remove the ignition key, and disconnect the spark plug wires.

1. Release hood latch assembly (2) and remove footrest.
2. Rotate locking arms upward on each side of the carrier frame to release carrier frame for tilting action.




Locking Arm Rotation

3. Install tilt bar into front of deck.



Tilt Bar Installed

4. Using the tilt bar, raise deck to the **TILT-UP** position and insert the deck hook into the tilt-up latch on the tractor body.



Deck Secured in Tilt-Up Position

5. Clean grass buildup underneath the deck using a pressure washer (and scraper if required).

NOTE: If the buildup is severe, it may be easier to clean the deck by removing the deck assembly from the tractor and standing the deck assembly on its “nose”.

NOTE: While some degree of material buildup in the mower deck housing can be tolerated, a point is finally reached **where cutting quality deteriorates and clogging begins to occur** because of too much buildup on the baffling and housing.




DANGER

Do not operate the mower with deck in tilt-up position. Do not move the tractor with the deck in the tilt-up position.

6. Lower the deck to the normal operating position and rotate locking arms **downward**.
7. Remove tilt bar and store on carrier frame.

8. Reinstall footrest by inserting locking fingers under deck plate and reattaching hood latch assembly.



Footrest Installation




CAUTION

Do not operate machine with deck locking arms disengaged.

Transaxle Cooling Fins

Keeping the cooling fins on the transaxles clean and free of obstruction is **essential to avoid overheating** the transmission fluid and shortening transmission life. The cooling fins should be checked **every 100 hours**; and cleaned if necessary.


To clean the fins, use compressed air and/or a pressure washer. Pay close attention to any build up on the transaxle housings. This may be the result of an oil leak. If an oil leak is noticed, contact your local Walker dealer.



Transaxle Cooling Fins

IMPORTANT: In case an oil leak develops on the input shaft, the cooling fan blowing dusty air and oil on the transmission will **quickly** pack the cooling fins with **oily dirt**. If this condition occurs, contact your dealer immediately to avoid overheating and damaging the transaxle.

An additional procedure in maintaining transaxle cooling is to inspect the cooling fans. Replace the fan(s) if blades are missing or damaged.



Transaxle Cooling Fans

CHECKING/SERVICING

**DANGER**

To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the spark plug wires.

Security of Air Filtration Components

NOTE: The following inspection is **only an external inspection** and should be done without “disturbing” the filtration components.

On a daily basis, visually inspect the external condition of the complete air cleaner system. The following items should be inspected:

1. Check the Cummins/Fleetguard OptiAir™ air cleaner canister for damage. Make sure the cover is in place and the cover latch is secure - do not run the engine without the air cleaner cover in place and secure.
2. Inspect the air intake hose for cracks, nicks, cuts, etc., and check the hose clamps for tightness.
3. Check to make sure the air flow indicator is in place and tight.

Battery

NOTE: For initial battery service during setup, refer to **Battery Service** in **Assembly Instructions**.

IMPORTANT: Make sure battery is securely mounted in the frame. A loose battery may cause damage to the case resulting in acid leakage and severe damage to the machine. A hazard may be created by damage to critical working parts and safety systems.

**CAUTION**

Important Battery Service, Installation, and Changing Tips for MBS26:

- Do not allow the battery cables to touch opposing terminals. When connecting battery cables attach the positive (+) cable to positive (+) battery terminal first, followed by negative (-) cable to negative (-) battery terminal.
- Never start the engine when the cables are loose or poorly connected to the battery terminals.
- Never disconnect battery while engine is running.
- Never use a quick battery charger to start the engine.
- Never “jump start” the engine using another source. Electricity fluctuations can damage the ECU (Electronic Control Unit).
- Always disconnect negative (-) battery cable lead before charging battery, and also unplug harness from ECU before performing any welding on equipment.

Electrolyte Level

The battery electrolyte level should be checked **after every 25 hours** of operation. To check electrolyte level:

1. Remove battery cell filler caps.
2. Check the electrolyte level. If the level is below the bottom of the vent well, fill with drinking water to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].
3. Replace filler caps.

IMPORTANT: DO NOT overfill the battery. Electrolyte will overflow through the vented caps onto parts of the machine and **WILL** result in severe corrosion.

Cleaning the Terminals

If battery terminals are corroded, **remove battery** from the mower. Using a wire brush, remove corrosion with a solution of **one part baking soda and four parts water**. Rinse with clean water. Coat the terminals with petroleum jelly or terminal protector spray to retard further corrosion.

Charging the Battery



DANGER

BATTERIES PRODUCE EXPLOSIVE GASES

- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

Check the battery charge by measuring the specific gravity of electrolyte; if specific gravity is less than 1.225, the battery will need to be charged as follows:

1. Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.
2. After charging the battery, use distilled water to adjust the electrolyte level to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].

Tire Pressure

Inflate tires to pressures shown below:

Deck Caster Wheel = 20 PSI (137 kPa)
 Drive = 15 PSI (103 kPa)
 Rear = 20 PSI (137 kPa)

Wheel Nuts Torque

Check **every 100 hours** the eight (8) Drive Tire mounting nuts. They should each be torqued to 75 to 85 ft-lbs. (101.7 to 115.2 N·m).

Sharpen Mower Blades

Check mower blade(s) for **straightness, sharpness, condition of the cutting edge, and balance every 10 hours** of operation (or more often when mowing abrasive type grass or operating on sandy soils). **Replace blades if worn, bent, cracked, or otherwise damaged** (refer to **REPLACING/REPAIRING the Mower Blades** in this section). Use the following procedure to check and sharpen blades:

NOTE: Keep blades sharp - cutting with dull blades not only yields a poor mowing job but slows the cutting speed of the mower and causes extra wear on the engine and blade drive by pulling hard.

1. Stop the engine, remove ignition key, and disconnect the spark plug wires **before** raising the mower deck to service blades.
2. Raise the deck and **secure it** in the **TILT-UP** position (refer to **Deck Secured in Tilt-Up Position** photo in **CLEANING of Grass Buildup in Mower Housing** in this section).



DANGER

NEVER operate cutter blades with the deck in the raised position.

NOTE: PTO shaft must be **disconnected** before checking blades for straightness.

3. Check the blades for **straightness** by marking the blade tip position inside the deck housing, and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.



WARNING

DO NOT try to straighten a blade that is bent. **NEVER** weld a broken or cracked blade. **ALWAYS** replace with a new blade to assure safety.

4. If the blade cutting edge is **dull or nicked**, it should be sharpened. Remove blades for sharpening by grasping the end of the blade using a rag or a thick, padded glove, while loosening and removing the bolt and washer that mounts the blade.
5. Grind cutting edge at the same bevel as the original. Sharpen only the top of the cutting edge to maintain sharpness.


NOTE: Blades can be sharpened with an electric blade sharpener, conventional electric grinder, or a hand file.




CAUTION

ALWAYS wear eye protection and gloves when sharpening a blade.

6. Check blade balance by positioning the blade **horizontally** on a blade balancer or use a nail or shaft through the center hole. If either end of the blade rotates downward, grind (remove) metal on that end until the blade will balance. The blade is properly balanced when neither end drops. Balance of a blade is generally maintained by removing an equal amount of material from each end of the blade when sharpening.



Mower Blade Profile for Sharpening



Blade Balanced on Magnetic Wall-Mounted Balancer

7. Mount the blade with wing tips pointing up into the housing. Reinstall the blade, washer, and bolt. **Tighten the bolt to 64 ft-lb (86.8 N·m).**

Drive Belts

Raise the body and inspect the condition of the four (4) drive belts **after every 25 hours** of operation -- engine/PTO drive and ground drive. If the belts show **signs of cracking or deteriorating**, the belts should be **replaced**. Refer to **REPLACING/REPAIRING the Drive Belts** in this section.

Spark Plugs

Every 200 hours, remove the spark plugs, inspect, clean, and reset the gap (or replace with a **new plug**). Clean spark plug with a wire brush. If the electrodes are burned short or pitted, replace the plug (refer to **Specifications** for the proper type of replacement plug). Check the spark plug gap with a wire-type feeler gauge and set the gap to 0.030 in. (0.76 mm). Reinstall and tighten to 18 ft-lb (24.4 N·m). Both spark plugs should be replaced yearly.

Fuel Lines and Clamps

NOTE: The MBS26 system is pressurized and should be serviced by a Walker dealer or Authorized Kohler engine service outlet.

Every year, inspect the fuel lines from the tanks to engine for deterioration or damage. Also, inspect the fuel line **clamps for tightness**. Good preventive maintenance calls for complete **replacement** of fuel lines and clamps **every two (2) years**.

PTO U-Joints

The PTO U-joints should be inspected **yearly** for looseness and wear. If either is noticed, the respective shaft or tube should be replaced. A worn U-joint can cause vibration and extensive damage to the PTO and deck gearboxes.

Blade Brake Action



WARNING

It is important to check and maintain blade brake action for safe operation of the machine.

Check the function of the cutter blade brake by engaging the blade clutch (PTO), operating the engine at full throttle, then disengaging the clutch and measuring how quickly the blades stop. Watch the rotation of the blade drive shaft as a visual indication that movement has stopped. If the brake is **working properly, all rotation will stop five (5) seconds after disengagement** of the clutch. If the brake system malfunctions -- blades do not stop in five (5) seconds -- adjust or repair the brake before operating the mower. Contact your Walker dealer for this service or refer to the Walker Service Manual.

Safety Switch System



WARNING

It is important to check and maintain the safety switch system for safe operation of the machine.

There are three (3) safety interlock switches on the tractor; Seat Switch, FSC Neutral - Park Switch, and PTO Switch.

NOTE: There is a 1 to 1-1/2 second time delay function on the seat switch to avoid engine power interruption when driving over bumps.

If any of the following conditions occur during starting or operating, a safety interlock switch may be malfunctioning. Contact your Walker dealer for troubleshooting and/or replacement.

- With an operator in the seat, the engine starts with the Forward Speed Control (FSC) and/or the PTO engaged.

- With an operator in the seat, the engine starts but dies soon after the Forward Speed Control (FSC) or PTO is engaged.

- **Without** an operator on the seat, the engine starts and continues to run with the Forward Speed Control (FSC) and/or PTO engaged.

- With an operator in the seat, the Forward Speed Control (FSC) and PTO disengaged and horn works, but the starter is not engaging.

Forward Speed Control Friction Lock

The FSC friction lock is designed to **hold the selected forward travel speed** when the steering levers are moved and yet the friction is not too heavy to make **moving the FSC control** difficult (too much friction). The procedure for checking the FSC friction lock is as follows:

1. Place the FSC in the full **FORWARD** position and pull both steering levers back; the FSC lever should not move. If the FSC lever moves back when the steering levers are pulled back, the **friction needs to be increased**.
2. With the steering levers held back, move the FSC lever back from the **FORWARD** position. With a proper amount of friction adjusted, the FSC lever should move back with a slight amount of resistance (friction). If the FSC lever movement is "stiff", **the friction needs to be decreased**.

If the FSC friction lock needs to be adjusted, contact your Walker dealer or refer to the Walker Service Manual.

REPLACING/REPAIRING



To prevent accidental starting of the engine when replacing parts or repairing the machine, remove the key from the ignition switch and disconnect the spark plug wires.


IMPORTANT: ALWAYS use genuine factory replacement parts. Substitute parts **CAN** result in product malfunction and possible injury to the operator and/or others.

Drive Belts

There are **four (4) individual belts** on the machine:

- Engine/PTO Belt [Matched Set (3)]
- Ground Drive Belt

The belts may be removed and replaced using the **procedures described on the following pages.**



Belt Locations (Engine Hidden for Clarity)


Engine/PTO Belt

1. To remove the engine/PTO belt:

- a. Remove wire lock pins (4), open belt guards.

- b. Relax belt by depressing idler arm.

- c. Roll the belt off the pulley and remove the belt.




Engine/PTO Belt (Belt Guards Open) (Engine Hidden for Clarity)

2. To replace the engine/PTO belt:

- a. Reverse the removal procedure to replace the engine belt.


- b. Secure wire on lock pin above tab on lower PTO guard.



Engine/PTO Belt (Belt Guards Closed) (Engine Hidden for Clarity)


Ground Drive Belt

1. To remove the ground drive belt:
 - a. Raise the spring-loaded idler to relax belt.
 - b. Slide belt off pulleys, then release the idler.



Ground Drive Belt Assembly (Disengaged)

2. Reverse the procedure to install the ground drive belt.




Ground Drive Belt Assembly (Engaged)

Fuel Filter - Model MBS26

WARNING

The MBS26 fuel system operates under high pressure. This system should be serviced by a Walker dealer or authorized Kohler service dealer.


Model MBS26 is equipped with a high-volume, high-pressure, 10-15 micron, in-line fuel filter. Replacement of this filter is recommended **every 1500 hours** of operation or more frequently under extremely dusty or dirty conditions. Because the MBS26 has a pressurized fuel system, fuel filter replacement should be done by a Walker dealer or authorized Kohler service dealer.



Fuel Filter Location

Fuel Filter - Model MBS

Model MBS is equipped with in-line fuel filters. Visually inspect the filter periodically, and replace the filter **yearly**.



Fuel Filter Location

IMPORTANT: Replace the fuel filter only in a clean area where the fuel line and connections will not be contaminated by any dust and dirt.

DANGER

Gasoline is extremely flammable and can be highly explosive. To minimize danger:

- Use only an approved fuel container for gasoline.
- **DO NOT** allow open flames or sparks near the machine while performing maintenance or refueling; **DO NOT** smoke while working with fuel.
- Wipe up spilled gasoline immediately and completely.

1. Expand and slide clamps on either side of the filter away from filter and pull fuel lines off filter.
2. Replace filter.

Mower Blades

Mower blades are removed and remounted as described in the **Sharpen Mower Blades** instructions (refer to **CHECKING/SERVICING to Sharpen Mower Blades** in this section). During the course of sharpening and inspecting mower blades, if there are **any of the following conditions of wear or damage, blades should be replaced** for reasons of safety and performance of the machine:

- An excessive amount of the **flat section** of the blade has been **ground away** (removed) when the blade is sharpened. Replace the blade **when less than a 3/4 in. (19 mm) flat section remains** at the blade tip.
- Examine ends of the blade carefully, especially the intersection where the flat section of the blade turns up to form the "wing tip" (refer to **Mower Blade Profile for Sharpening** illustration in **Sharpen Mower Blades** instructions). Since sand and abrasive material can wear metal away in this area, the blade should be **replaced when metal thickness has worn to 1/16 in. (1.6 mm) or less**.

DANGER

When blades are operated over sandy soil, and if blades are allowed to wear, a “slot” may be worn into the wing tip of blade. Eventually a piece of the blade may break off creating a serious potential for injury or damage.

- Check the blades for **straightness** by marking blade tip position inside the deck housing and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.
- Inspect the blade surface, especially in formed areas, for **cracks**. Replace the blade if any cracks are found.

WARNING

DO NOT try to straighten a blade that is bent. NEVER weld a broken or cracked blade. ALWAYS replace with a new blade to assure safety.

Reinstall the blades following procedure from **Sharp-enMowerBlades** instructions. If blades are replaced, always use **Walker original equipment blades** to ensure safety and optimum performance. The quality and performance of **replacement blades offered by other manufacturers** cannot be guaranteed, they could be dangerous.

CAUTION

ALWAYS use genuine factory replacement parts. Substitute parts CAN result in product malfunction and possible injury to the operator.

ADJUSTMENTS

Transmission Control

IMPORTANT: The proper adjustment of the transaxle control stops is **essential** for efficient operation and life of the transaxle. These stops are properly adjusted at the factory and should only require readjustment if the transaxle or related control linkage is removed or changed.


NOTE: It would not be unusual for a new machine, after initial 5 or 10 hours of operation, to begin to not travel straight (this is due to the break-in of the transaxles).

Steering Lever Position Adjustment - Step 1

NOTE: For proper operation, the steering levers should be adjusted to sit evenly using the following procedure.


1. Examine the steering levers to make sure they are **parallel front to back** in relation to one another. If they are not equal, adjust accordingly. (The handles may or may not be even at this point.)

NOTE: The **LH steering lever is non-adjustable**. This procedure will require adjustment of the RH lever to make it even with the LH lever.



Lever Alignment


2. Adjust the position of the RH lever by turning the stop bolt in the Speed Control Actuator in or out. Turning the stop bolt in will make the RH lever move back, and turning it out will make it move forward. Tighten the locknut.



Stop Bolt Location

Steering Handles Adjustment - Step 2


1. An adjustment range of approximately 3 in. (76.2 mm) is available on the steering handles - the handles can be adjusted forward or aft depending on the arm length of the operator. The handles can be adjusted by loosening the locknut at the pivot point and the locknut holding the handle in position in the adjustment slide. Adjust the handles into the most comfortable position and tighten both locknuts.




Steering Lever Adjustment

Neutral Position Adjustment - Step 3

1. With the Forward Speed Control (FSC) in **NEUTRAL**, the lever should be straight up. Adjust by loosening the jam nuts on the FSC Rod and turn the rod to attain the straight up position. Tighten the jam nuts.




FSC Position



Steering Adjustment

2. The initial adjustment for neutral is to loosen the jam nuts on each end of the Control Rod and turn the rod to achieve a measurement of 5 in. (127 mm) between the jam nuts. Be sure to tighten jam nuts before making the measurement.




Actuator Rod Length Adjustment

3. Block the tractor up so the drive tires are off the ground.
4. With the FSC in **NEUTRAL**, start the engine. (Operate first at idle and then normal operating speed) and **check for movement of drive wheels**.

NOTE: If the engine will not start, check and adjust the neutral safety switch (refer to *FSC Switch - Neutral Adjustment - Step 6*).

5. With the FSC in the **NEUTRAL** position and the engine running, the wheels should not move. If a drive tire is moving, the Control Rod on that side is out of adjustment. Adjust that side to achieve neutral. Now both transaxles are in the neutral window.




Neutral Window (Front Body Hidden for Clarity)

6. One at a time adjust the left and right Control Rods to find the center of the neutral window. Shorten the rods until the drive tire turns forward then lengthen it until the drive tire turns in reverse (approximately 1 turn). Position the rods halfway between forward and reverse. Tighten the jam nuts.
7. Lower drive tires onto ground.

Full Forward Speed Adjustment - Step 4


1. Move the FSC to the full **FORWARD** speed position.
2. Raise the body. The set screws in the left and right Transmission Control Arms should not be contacting the locating stud in the transaxle. If they are, back the set screws out until they do not touch.



**Neutral Travel End
(Shown with Parts Removed for Clarity)**

Straight Tracking Adjustment - Step 5


1. Sit in the seat, start the engine, set throttle at full speed, and with the FSC in the **NEUTRAL-PARK** position check for movement of either drive wheel (if either wheel moves backward or forward, refer to the *Neutral Position Adjustment - Step 3* and readjust).
2. Check for straight ground tracking on a level surface (with hands off the steering levers). Set the FSC at several different speeds and observe if the mower moves in a straight line (use cement joint or other line on ground for reference).
3. If travel is not straight, shorten the control rod of the slow side (adjust in 1/8 turn increments) to match the faster side while maintaining the neutral position. If straight tracking and neutral can not be achieved, turn the control rod back to where neutral can be achieved.
4. Lengthen the control rod of the faster side (adjust in 1/8 turn increments) to match the slower side while maintaining the neutral position.
5. If the forward travel is straight throughout the speed range, except at maximum speed - place the FSC in full **FORWARD**, turn the set screw in the Transmission Control Arm, of the faster side, in until it contacts the hydro stud. (Turning the setscrew slows the wheel.) **Turn the setscrew in an additional 1/8 turn.** Recheck for equal full forward speed. Adjust this set screw until equal full forward speed is achieved. Tighten the jam nut.




Neutral Travel End Adjust

FSC Switch - Neutral Adjustment - Step 6

1. Place the FSC in **NEUTRAL** position. Loosen mounting screws and adjust switch up or down accordingly.



FSC Switch Location



**FSC Switch Adjustment
(Side View Through Chassis)**

Forward Speed Control Friction Adjustment - Step 7



FSC Position with Levers


1. Place the FSC in the full forward position and pull both steering levers back; the FSC lever should not move. If the FSC lever moves back the **friction needs to be increased**.
2. With the steering levers held back, move the FSC lever back from the **FORWARD** position. With a proper amount of friction adjusted, the FSC lever should move back with a slight amount of resistance (friction). If the FSC lever movement is "stiff", the **friction needs to be decreased**.
3. The FSC friction is **increased** or **decreased** by **tightening** or **loosening** the **friction adjustment nut**. Loosen or tighten the nut and check the control function until the conditions of both steps 1 and 2 (above) are met.

Blade Clutch (PTO)

Clutch Engagement/Belt Tension

The clutch engagement and PTO belt tension are adjusted using the clutch rod. Initially, after installing new PTO belts, **after 10 hours and every 100 hours** thereafter, check and adjust for the dimensions as shown in the **PTO Clutch Engaged** and **PTO Clutch Disengaged** illustrations.

Adjust the length of the clutch rod to achieve a bolt head clearance of 1/4 in. to 5/16 in. (6.35 mm to 7.94 mm) with the clutch engaged. To adjust length: remove ball joint from clutch arm, **shorten** the clutch rod to **decrease** this measurement or **lengthen** the clutch rod to **increase** this measurement. If adjustments are needed more frequently than every 100 hours to maintain dimensions, it may suggest problems with pulley wear or belt misalignment.




PTO Clutch Engaged

Clutch Disengagement/Brake Action

WARNING

It is important to check and maintain blade brake action for safe operation of the machine.

The **declutched or disengaged position** of the blade clutch idler pulley is adjustable and is set to give belt release **without excessive slack** and to apply the blade brake. The blade brake is activated by the brake band connected to the clutch engagement arm. The brake is designed to stop the blades within five (5) seconds after disengaging the clutch.



PTO Clutch Disengaged


Use the following procedures to check and adjust clutch disengagement and brake action:

Idler Pulley Maximum Travel Adjustment - Step 1

Loosen the brake band adjustment nut allowing stop arm and stop nut to make contact (refer to **Blade Brake Band Adjustment** illustration).

1. Adjust the pivot stop bolt to give 1-5/8 in. to 1-3/4 in. (41 mm to 44 mm) pulley travel from "clutch engaged" to "clutch disengaged".
2. Check and adjust the pulley travel, first engage the clutch, then measure the distance the pulley travels as the clutch is disengaged and the stop arm contacts the stop bolt.

NOTE: This adjustment will prevent excessive pulley travel that can cause belts to develop too much slack, causing possible belt derailment upon disengagement.




Clutch Idler Pulley Travel

Blade Brake Band Adjustment - Step 2


After the maximum pulley travel is set, adjust the working travel of the clutch idler pulley by adjusting the brake band nut and make the following adjustment as needed:

1. Adjust the blade brake band, using the adjustment nut until pulley travel is approximately 5/8 in. to 3/4 in. (16 mm to 19 mm) from engaged to disengaged.

NOTE: As blade brake band/drum wears, pulley travel will increase and it will be necessary to adjust the blade brake band nut to maintain these dimensions.



Clutch Idler Pulley Travel Adjustment



Blade Brake Band Adjustment

2. After adjustments are complete, check blade brake action as described in **CHECKING/SERVICING** the **Blade Brake Action** in this section. If blades do not stop within five (5) seconds, check the following:
 - a. Make sure clutch and brake linkage are working freely (no binding).
 - b. Check the brake band lining.
 - c. Check the brake drum on the pulley. If excessive wear is present, it will be necessary to replace worn parts.

ELECTRICAL SYSTEM

For troubleshooting, refer to the **WIRING SCHEMATIC**.


IMPORTANT: Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.

TRACTOR AND DECK DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D	SD
Walker Product and Operation Decals					
1	2802-2	RH Fender	Body, RH near Seat	1	
2	2010-4	Fuel Transfer (MBS)	Transfer Mount, RH	1	
	2010-5	Fuel Transfer (MBS26)	Transfer Mount, LH	1	
3	5800-6	Decal, Walker 6-3/4"	Rear Body (one on each side)	2	
4	2802-1	LH Fender (MBS)	Body, LH near Seat	1	
	2802-3	LH Fender (MBS26)	Body, LH near Seat	1	
5	9804	Axle Lockout	Chassis	2	
6	5856	Made in USA	Body	1	
7	5803	Walker Manufacturing Logo	Body	1	
8	2748	Cutting Height Adjustment	Carrier Frame	1	
9	5800-5	Decal, Walker 8"	Deck Footrest, Front	1	
Danger Decals Warning Decals Caution Decals					
10	5805	Caution, Engine Exhaust	Rear Body	1	
11	6810	Danger, Engine Exhaust	Engine, LH Side (MBS) RH Side (MBS26)	1	
12	2107-4	Decal, Belt Routing	Rear Body, Underside	1	
13	4107-1	Danger, Rotating Components	Air Cleaner Bracket	1	
14	5808	Danger, Rotating Blades	Deck Housing (one on each end)	2	
15	8647	Danger, Tilt-Up	Carrier Frame	1	
16	8653-1	Transport Warning	Deck Housing	1	
17	8653	Caution, Pivot Joint	Carrier Frame	2	
18	2749-2	Decal, Drive Belt Routing (DSD60)	Deck Housing	1	
	2749-1	Decal, Drive Belt Routing (DRD52)	Deck Housing	1	
19	5848	Danger, Side Discharge Shield (DSD60)	Side Discharge Shield	1	
Maintenance Decals					
20	2105-8	RH Decal, 27 HP	Rear Body, RH Side	1	
	2105-6	RH Decal, 26 HP	Rear Body, RH Side	1	
21	2105-9	LH Decal, 27 HP	Rear Body, LH Side	1	
	2105-7	LH Decal, 26 HP	Rear Body, LH Side	1	
22	5855	Important, Engine Cooling	Engine	1	
23	2807-1	Decal, Oil Pres./Head Temp. (MBS)	Body	1	
	2807-2	Decal, Systems Warning (MBS26)	Body	1	
24	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1	
25	8746	Universal Joint Lube	Mount Bracket / PTO Guard	1	
26	2732	Decal (60")	Deck Housing, Front	1	
	8732	Decal (52")	Deck Housing, Front	1	
27	2724-7	Decal, Belt Tensioner	Deck Housing	1	
Option Decals (applied only to units with corresponding Options installed)					
28	5877	Lights, On-Off	Body	1	

NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR AND DECK DECALS



BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D		ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	
Body & Seat Assembly									
1	2103-1	Seat	1		46	2430	Deck Support Arm, RH (Includes Item # 24)	1	
2	2105-1	Rear Body (Includes Item # 3)	1		Deck Arm Adapter Kit*				
	2105-2	Rear Body, MBS26 (Includes Item # 3)	***		47	2431-1	Deck Arm Adapter, LH (Includes Item # 24)	1	
3	2190-1	Insulation Foam Pad	1		48	5775-2	Hitch Pin (#6)	2	
4	5845	Rubber Bumper (1.50 x 1.25)	2		49	2430-1	Deck Arm Adapter, RH (Includes Item # 24)	1	
5	5146	10mm Ball Stud	2		50	2744-2	Counter Weight Spring Extension	1	
6	2145	Gas Spring	1		51	2744-4	1/4" Quick Link	1	
7	5180	Edge Molding, Lever Opening	2		52	2744-5	Chain	1	
8	2100-3	Front Body Doubler	1		Tilt-Up Latch Assembly**				
9	2504-4	Hinge (22.5)	1		53	5847	Plastic Tip	1	
10	2100-1	Front Body	1		54	5744-20	Spring Arm, Tilt-Up Latch	1	
	2100-2	Front Body, MBS26	***		55	5744-10	Spring Pivot Bushing	1	
11	5989-5	Dome Plug (7/16)	1		56	5744-15	Compression Spring (3/8 x 5/8)	1	
12	2383	Body Latch Hook	1		57	5744-13	Mount Angle, LH	1	
13	7854	Plastic Tip, Red	1		58	5744-12	Hook, Tilt-Up Latch	1	
14	7222	Extension Spring (1/4 x 3)	1		59	5744-14	Mount Angle, RH	1	
15	5989-4	Dome Plug (3/8)	2		Fasteners				
16	5989-3	Dome Plug (5/16)	2		F002	10-24 Keps Nut	5		
Chassis Assembly					F004	1/4-20 Keps Nut	12		
17	2010-10	Flex Coupling Guard, RH	1		F005	1/4-20 ESNA Nut	2		
18	2010-11	Flex Coupling Guard, LH	1		F009	5/16-18 Whiz Locknut	20		
19	2390-1	Battery Pan	1		F013	3/8-16 Whiz Locknut	2		
20	2046-1	Gas Tank Mount, LH	1		F020	5/16-18 ESNA Nut	1		
21	2300-3	Chassis Frame	1		F025	10-24 x 3/8 PPHMS	5		
22	2046	Gas Tank Mount	1		F029	1/4-20 x 1/2 Hex Bolt	2		
23	2325-8	Belt Guide	1		F031	1/4-20 x 5/8 Hex Bolt	2		
Tail Wheel Assembly					F034	5/16-18 x 3/4 Hex Bolt	10		
24	5830	Grease Fitting	6		F050	1/4 SAE Washer	1		
25	2201-2	Fiberglide Thrust Washer	2		F093	5/16-18 x 1 Hex Bolt	1		
26	2201-3	Fiberglide Bearing (1-5/8)	2		F151	3/8-16 x 7/8 Hex Bolt	2		
27	2300-6	Tail Wheel Pivot (Includes Items # 24 & 28)	1		F183	.312 x .700 x .074 Washer	4		
28	5830-3	Grease Fitting (45 Deg.)	1		F205	5/16-18 x 1/4 Set Screw (Knurl Point)	2		
29	2201-4	Washer (2-1/4 x 7/16 x 1/4 Thk)	1		F218	7/16 Split Lock Washer	5		
30	8769-8	Dust Cap, Deck Caster	2		F219	7/16-14 x 1-1/4 Hex Bolt	5		
31	8769-6	Bearing Cone (1" ID)	4		F236	1/4-20 x 1-3/4 Hex Bolt	2		
32	8769-5	Bearing Cup (2 x 1-5/8)	4		F246	1/4-20 x 1/2 PTHMS	5		
33	8769-7	Seal	2		F256	7/16 SAE Washer	1		
34	2770	Caster Wheel Fork	2		F341	Coil Roll Pin (7/64 x 9/16)	1		
35	8039	Nut, Tail Wheel Axle	2		F342	5/16 Conical Washer	2		
36	8038-1	Spacer, Tail Wheel Axle (.750 x ID x 1.125 OD)	2		F344	3/4-16 Slotted Hex Nut	2		
37	8768-2	Seal, Reverse Lip	2		F347	3/4 SAE Washer	2		
38	8037	Bearing Cone (3/4 ID)	4		F348	1/8 x 1-1/2 Cotter Pin	2		
39	8035	Tail Wheel & Tire (13 x 5.00-6) (W/Bearing Race)	2		F430	7/16-20 ESNA Nut	2		
40	8037-1	Seal, Outer (1-3/4 x 1-1/8)	2		F442	1/4-20 x 5/8 PTHMS	5		
41	7038	Tail Wheel Axle (3/4 x 5-9/16)	2		F446	7/16-20 x 3-1/2 Grd 8 Bolt	2		
Deck Support Arm & Hitch Assemblies					* Complete Deck Arm Adapter Kit available by ordering kit 2430-10. This kit allows the use of all Side Discharge Decks with the MBS Tractors.				
42	2300-9	Deck Arm Support Mount	1		** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5747.				
43	6840-1	Support Arm Bushing (2-1/16)	2		*** Service Part Only				
44	2775	Lynch Pin (5/16 x 1-1/4)	2						
45	2431	Deck Support Arm, LH (Includes Item # 24)	1						

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

[illegible]

Use only genuine **Walker®** replacement parts.

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				51	5214-2	Ball Joint (5/16-24) (Nylon Lined)	1
1	4850	Handle Grip, Black	1	52	7226	Compression Spring (3/4 x 2-1/2)	1
2	2358-1	Clutch Lever, MBS (Includes Items # 1 & 3)	1	53	7380	Knuckle Joint	1
3	5830-3	Grease Fitting (45 Deg.)	3	Fasteners			
4	4303-7	Clutch Actuator Bolt (5/16)	1	F004	1/4-20 Keps Nut	5	
5	2306-2	Oilite Flanged Bushing	2	F008	5/16-24 Keps Nut	1	
6	5830	Grease Fitting	2	F009	5/16-18 Whiz Locknut	13	
7	2325-7	Clutch Arm (Includes Items # 5 & 6)	1	F010	5/16-24 ESNA Nut	1	
8	5221-1	Extension Spring (3/4 x 5)	1	F012	3/8-16 Keps Nut	1	
9	2358-10	Clutch Rod	1	F013	3/8-16 Whiz Locknut	2	
10	5214-4	Ball Joint (5/16-24) W/O STD	2	F024	5/16-24 Jam Nut	2	
11	2358-9	Clutch Pivot Base	1	F029	1/4-20 x 1/2 Hex Bolt	1	
12	5214-13	Ball Joint (3/8)	1	F031	1/4-20 x 5/8 Hex Bolt	13	
13	2358-8	Adjustor Brace	1	F034	5/16-18 x 3/4 Hex Bolt	9	
14	7775-6	Wire Lock Pin (2-1/2")	3	F035	5/16-18 x 1-1/4 Hex Bolt	3	
15	2302-4	Right Hand Shoe	1	F049	5/16 SAE Washer	2	
16	2302-7	Upper Shoe, LH	1	F058	1/4 Wave Spring Washer	6	
17	2302-3	Left Hand Shoe	1	F060	AN960516 Washer	2	
18	2349-7	Bearing Mount	1	F061	1/4 Star Lock Washer	1	
19	2406-5	Spacer	1	F069	3/32 x 1/2 Cotter Pin	1	
20	2236-5	PTO Pulley (4.5/AAA)	1	F091	5/16-18 x 5/8 Hex Bolt	1	
21	2274-9	Collar (1")	2	F104	1/4-20 x 3/4 PFH Bolt	2	
22	2274-8	Bearing (1")	2	F120	AN960416 Washer	8	
23	2359-1	Brake Band / Guard Mount	1	F146	1/4-20 Jam Nut	1	
24	7775-8	Wire Lock Pin (4")	1	F149	1/4 x 1/4 x 1-1/2 Key	1	
25	2302-5	PTO Shoe	1	F168	5/16 Split Lock Washer	1	
26	2410-2	Drive Shaft	1	F170	5/16 x 1 x 7/64 Flat Washer (Zinc Plate)	1	
27	7275-9	Quick Coupler Installation Tool	**	F171	5/16-18 x 3/8 Set Screw	1	
28	7275-16	Universal Joint Tube Assembly / Spline	1	F178	1/4 x 1 Fender Washer	1	
29	2274-7	PTO Bearing Housing	1	F182	1/4 x 5/8 x 1/8 Washer	1	
30	2274-10	PTO Drive Shaft Assembly (Includes Items # 21, 22, 26 & 29)	*	F211	1/4-20 x 7/8 Hex Bolt	1	
31	2302-6	Shoe Mount, LH	2	F217	7/16-14 Hex Nut	2	
32	2358-7	Clutch / Pivot Stop MBSSD	1	F218	7/16 Split Lock Washer	2	
33	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1	F219	7/16-14 x 1-1/4 Hex Bolt	2	
34	4359-2	Brake Band Link, Rear	1	F241	.375 x .875 x .10 Washer	1	
35	8304	Brake Band (14-1/2)	1	F255	5/16-18 x 1-1/2 Hex Bolt	4	
36	4359-1	Brake Band Link, Front	1	F298	3/8-24 Jam Nut	1	
37	2410-2	Drive Shaft	1	F350	1/4-20 LP Nylock	9	
38	2265	Bearing (20mm)	4	F389	3/8-16 x 2-3/4 Hex Bolt	1	
39	2406-7	Pivot Shaft Spacer	1	F431	1/4-20 x 3-1/2 Hex Bolt	1	
40	2236-1	Idler Pulley (4.5/AAA)	2	F435	1/4 x 1/4 x 1-1/4 Key	2	
41	2230	Engine PTO Belt / Set (3)	1	F450	Washer 5/8 x 2 x 1/4	1	
42	2236-6	Pulley (Includes Items # F149 & F171)	1	F452	5/8-18 Nylon Locknut	1	
43	2236-4	Idler Pulley Shaft	1	F473	5/16-18 x 5 Hex Bolt	1	
44	7201-3	Fiberglide Bearing	2	F476	3/8-16 x 6-1/2 Hex Bolt	1	
45	7201-9	Inner Race	1	F484	Washer .370 ID x 1.0 OD x .120	2	
46	2359-2	Clutch Engagement (Includes Items # 3 & 44)	1	* Service Part Only			
47	2349-6	Flanged Bearing (Includes Item # 6)	1	** The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO Drive Shaft.			
48	4302-2	Shoe Mount	1				
49	7377	Plastic Washer (1 x .438 x .025)	2				
50	7378	Pivot Bearing (7/16 x 9/16)	1				

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

Refer to
Engine Group
(Model MBS26 or MBS)

Refer to
Hydrostatic Ground
Drive Assemblies

Refer to
Body / Chassis Assembly

Diagram illustrating the exploded view of the Hydrostatic Ground Drive Assembly, showing various components and their assembly sequence. Key components and part numbers include:

- Engine Group (Model MBS26 or MBS)
- Hydrostatic Ground Drive Assemblies
- Body / Chassis Assembly
- Components labeled with part numbers: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, F004, F009, F024, F035, F049, F058, F060, F061, F069, F070, F084, F091, F104, F120, F149, F168, F170, F178, F182, F217, F219, F241, F255, F298, F301, F304, F350, F435, F450, F452, F473, F484, F509, F531, F535, F549, F558, F561, F569, F570, F584, F591, F604, F609, F624, F635, F649, F658, F660, F661, F669, F670, F684, F691, F704, F720, F749, F768, F770, F784, F791, F804, F809, F824, F835, F849, F858, F860, F861, F869, F870, F884, F891, F904, F909, F924, F935, F949, F958, F960, F961, F969, F970, F984, F991, F1004, F1009, F1024, F1035, F1049, F1058, F1060, F1061, F1069, F1070, F1084, F1091, F1104, F1120, F1149, F1168, F1170, F1184, F1191, F1204, F1209, F1224, F1235, F1249, F1258, F1260, F1261, F1269, F1270, F1284, F1291, F1304, F1309, F1324, F1335, F1349, F1358, F1360, F1361, F1369, F1370, F1384, F1391, F1404, F1409, F1424, F1435, F1449, F1458, F1460, F1461, F1469, F1470, F1484, F1491, F1504, F1509, F1524, F1535, F1549, F1558, F1560, F1561, F1569, F1570, F1584, F1591, F1604, F1609, F1624, F1635, F1649, F1658, F1660, F1661, F1669, F1670, F1684, F1691, F1704, F1709, F1724, F1735, F1749, F1758, F1760, F1761, F1769, F1770, F1784, F1791, F1804, F1809, F1824, F1835, F1849, F1858, F1860, F1861, F1869, F1870, F1884, F1891, F1904, F1909, F1924, F1935, F1949, F1958, F1960, F1961, F1969, F1970, F1984, F1991, F2004, F2009, F2024, F2035, F2049, F2058, F2060, F2061, F2069, F2070, F2084, F2091, F2104, F2109, F2124, F2135, F2149, F2158, F2160, F2161, F2169, F2170, F2184, F2191, F2204, F2209, F2224, F2235, F2249, F2258, F2260, F2261, F2269, F2270, F2284, F2291, F2304, F2309, F2324, F2335, F2349, F2358, F2360, F2361, F2369, F2370, F2384, F2391, F2404, F2409, F2424, F2435, F2449, F2458, F2460, F2461, F2469, F2470, F2484, F2491, F2504, F2509, F2524, F2535, F2549, F2558, F2560, F2561, F2569, F2570, F2584, F2591, F2604, F2609, F2624, F2635, F2649, F2658, F2660, F2661, F2669, F2670, F2684, F2691, F2704, F2709, F2724, F2735, F2749, F2758, F2760, F2761, F2769, F2770, F2784, F2791, F2804, F2809, F2824, F2835, F2849, F2858, F2860, F2861, F2869, F2870, F2884, F2891, F2904, F2909, F2924, F2935, F2949, F2958, F2960, F2961, F2969, F2970, F2984, F2991, F3004, F3009, F3024, F3035, F3049, F3058, F3060, F3061, F3069, F3070, F3084, F3091, F3104, F3109, F3124, F3135, F3149, F3158, F3160, F3161, F3169, F3170, F3184, F3191, F3204, F3209, F3224, F3235, F3249, F3258, F3260, F3261, F3269, F3270, F3284, F3291, F3304, F3309, F3324, F3335, F3349, F3358, F3360, F3361, F3369, F3370, F3384, F3391, F3404, F3409, F3424, F3435, F3449, F3458, F3460, F3461, F3469, F3470, F3484, F3491, F3504, F3509, F3524, F3535, F3549, F3558, F3560, F3561, F3569, F3570, F3584, F3591, F3604, F3609, F3624, F3635, F3649, F3658, F3660, F3661, F3669, F3670, F3684, F3691, F3704, F3709, F3724, F3735, F3749, F3758, F3760, F3761, F3769, F3770, F3784, F3791, F3804, F3809, F3824, F3835, F3849, F3858, F3860, F3861, F3869, F3870, F3884, F3891, F3904, F3909, F3924, F3935, F3949, F3958, F3960, F3961, F3969, F3970, F3984, F3991, F4004, F4009, F4024, F4035, F4049, F4058, F4060, F4061, F4069, F4070, F4084, F4091, F4104, F4109, F4124, F4135, F4149, F4158, F4160, F4161, F4169, F4170, F4184, F4191, F4204, F4209, F4224, F4235, F4249, F4258, F4260, F4261, F4269, F4270, F4284, F4291, F4304, F4309, F4324, F4335, F4349, F4358, F4360, F4361, F4369, F4370, F4384, F4391, F4404, F4409, F4424, F4435, F4449, F4458, F4460, F4461, F4469, F4470, F4484, F4491, F4504, F4509, F4524, F4535, F4549, F4558, F4560, F4561, F4569, F4570, F4584, F4591, F4604, F4609, F4624, F4635, F4649, F4658, F4660, F4661, F4669, F4670, F4684, F4691, F4704, F4709, F4724, F4735, F4749, F4758, F4760, F4761, F4769, F4770, F4784, F4791, F4804, F4809, F4824, F4835, F4849, F4858, F4860, F4861, F4869, F4870, F4884, F4891, F4904, F4909, F4924, F4935, F4949, F4958, F4960, F4961, F4969, F4970, F4984, F4991, F5004, F5009, F5024, F5035, F5049, F5058, F5060, F5061, F5069, F5070, F5084, F5091, F5104, F5109, F5124, F5135, F5149, F5158, F5160, F5161, F5169, F5170, F5184, F5191, F5204, F5209, F5224, F5235, F5249, F5258, F5260, F5261, F5269, F5270, F5284, F5291, F5304, F5309, F5324, F5335, F5349, F5358, F5360, F5361, F5369, F5370, F5384, F5391, F5404, F5409, F5424, F5435, F5449, F5458, F5460, F5461, F5469, F5470, F5484, F5491, F5504, F5509, F5524, F5535, F5549, F5558, F5560, F5561, F5569, F5570, F5584, F5591, F5604,

Use only genuine **Walker®** replacement parts.

ENGINE GROUP (MODEL MBS26)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Precleaner Assembly			
1	8046-11	Fuel Tank, 4.7 Gallon, Gas (Includes Item # 3)	2 	36	7840	Hose Clamp (1-5/16 to 2-1/4)	2 
2	5082-2	Fuel Cap Seal	2 	37	2012-1	Air Intake Hose	1 
3	5082	Fuel Tank Cap (Includes Item # 2)	2 	38	2088-10	Air Cleaner Assembly (Includes Items # 38-43)	* 
4	5083-1	Bushing, Rubber (Fits 5083)	4 	39	5091-4	Air Flow Indicator	1 
5	5879-5	Stepless Ear Clamp (5/8)	21 	40	2088-1	Air Cleaner Band	1 
6	7046-1	Fuel Return Tube	2 	41	2090-3	Safety Filter Insert	1 
7	5083-8	Tank Tube (13")	2 	42	2090-1	Air Cleaner Cartridge	1 
8	7018-3	Hose (5/16 x 46)	3 	43	2088-2	Air Cleaner Cap	1 
9	5086-7	Hose (1/4 x 6)	2 	44	2090-2	Vacuator Valve	1 
10	5020-2	Fuel Filter, In Tank	2 	Choke and Throttle Assemblies			
11	5975-3	Cable Tie (50# x 7")	5 	45	8123	Insulating Sleeve (3/8 x 6)	1 
12	7015-16	Hose (5/16 x 14-1/2)	1 	46	2108-4	Control Cable (68")	1 
13	7018	Hose (5/16 x 9)	2 	47	5108-1	Control Lever, Throttle	1 
14	7018-1	Hose (5/16 x 10)	3 	48	5108-5	Throttle Control Knob, Red	1 
15	7018-2	Hose (5/16 x 12-1/2)	1 	49	5108-11	Friction Washer (.062)	1 
16	NS	Filter (Kohler)	1	50	7108	Control Assembly (Includes Items # 47, 49, 51-53 & F201)	1 
17	2010-6	Fuel Valve	1 		2108-3	Throttle Control and Cable Assembly (Includes Items # 47-49, 51-54, F002, F005, F050, F164 & F201)	* 
18	2010-2	Fuel Transfer Mount	1 	51	5108-8	Control Bracket	1 
19	2010-7	Hose Reducer (5/16-1/4)	1 	52	5108-10	Friction Washer (.125)	1 
20	NS	Clamp (Kohler)	2	53	5108-7	Control Lock Tab	1 
21	NS	Fuel Pump (Kohler)	1	54	5172	Bearing, Delrin (.255 ID x .379 OD x .250)	1 
22	NS	Fuel Regulator (Kohler)	1				
23	5086-9	Hose (1/4 x 5)	1 				
24	8026-14	Clamp, Loop Style	1 				
25	NS	Filter (Kohler)	1				
Engine Assembly				Fasteners			
26	NS	Rectifier	*	F002	10-24 Keps Nut	14 	
27	8016-4	Regulator Mount	1 	F004	1/4-20 Keps Nut	4 	
28	NS	27 HP Engine (Kohler)	*	F005	1/4-20 ESNA Nut	1 	
29	NS	Muffler	*	F009	5/16-18 Whiz Locknut	4 	
30	NS	Oxygen Sensor (Kohler)	1	F025	10-24 x 3/8 PPHMS	6 	
31	2104	Body Support	1 	F026	10-24 x 1/2 PPHMS	7 	
32	4845	Rubber Bumper (1.0 x .625)	2 	F031	1/4-20 x 5/8 Hex Bolt	4 	
33	NS	Kohler Nut	*	F034	5/16-18 x 3/4 Hex Bolt	2 	
34	2013-4	Shield Side	2 	F050	1/4 SAE Washer	1 	
35	2013-3	Muffler Heat Shield	1 	F164	10-24 x 1/4 x 3/8 SHL Bolt	1 	
				F175	1/2 Split Lock Washer	4 	
				F184	1/4-20 x 1/2 Hex Bolt, SS	4 	
				F185	1/4 Internal Star Lock Washer, SS	4 	
				F201	1/4 Belleville Spring Washer	2 	
				F439	1/2-13 x 1-3/4 Hex Bolt	4 	

* Service Part Only

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

ENGINE GROUP (MODEL MBS26)



Effective Date 09-15-10

Use only genuine **Walker®** replacement parts.


ENGINE GROUP (MODEL MBS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Choke and Throttle Assemblies			
1	8046-11	Fuel Tank, 4.7 Gallon, Gas (Includes Item # 3)	2 	34	2109-4	Control Cable (62")	1 
2	5082-2	Fuel Cap Seal	2 	35	2108-4	Control Cable (68")	1 
3	5082	Fuel Tank Cap (Includes Item # 2)	2 	36	8123	Insulating Sleeve (3/8 x 6)	1 
4	5083-8	Tank Tube (13")	2 	37	5108-1	Control Lever, Throttle / Choke	2 
5	5083-1	Bushing, Rubber (Fits 5083)	2 	38	5108-5	Throttle Control Knob, Red	1 
6	5086-7	Hose (1/4 x 6)	2 	39	5108-11	Friction Washer (.062)	2 
7	5020-2	Fuel Filter, In Tank	2 	40	5108-6	Choke Control Knob, Black	1 
8	5879-3	Hose Clamp (1/2)	7 	41	7108	Control Assembly (Includes Items # 37, 39, 42-44 & F201)	2 
9	5086-10	Hose (1/4 x 9)	1 		2108-3	Throttle Control and Cable Assembly (Includes Items # 37-39, 42-45, F002, F005, F050, F164 & F201)	* 
10	2010-3	Fuel Valve	1 		2109-3	Choke Control and Cable Assembly (Includes Items # 37, 39, 40, 42-45, F002, F005, F050, F164 & F201)	* 
11	2010-2	Fuel Transfer Mount	1 				
12	NS	Kohler Hose	*	42	5108-8	Control Bracket	2 
13	5020	Fuel Filter	1 	43	5108-10	Friction Washer (.125)	2 
14	5086-11	Hose (1/4 x 12)	1 	44	5108-7	Control Lock Tab	2 
15	5975-3	Cable Tie (50# x 7")	4 	45	5172	Bearing, Delrin (.255 ID x .379 OD x .250)	1 
16	5086-12	Hose (1/4 x 46)	1 				
17	7833-2	Cable Clamp (1 x 1/4)	2 				
Engine Assembly				Fasteners			
18	NS	27 HP Engine (Kohler)	*	F002	10-24 Keps Nut	12 	
19	NS	Muffler	*	F004	1/4-20 Keps Nut	2 	
20	2104	Body Support	1 	F005	1/4-20 ESNA Nut	2 	
21	4845	Rubber Bumper (1.0 x .625)	2 	F009	5/16-18 Whiz Locknut	4 	
22	NS	Kohler Nut	*	F025	10-24 x 3/8 PPHMS	8 	
23	2013-4	Shield Side	2 	F026	10-24 x 1/2 PPHMS	2 	
24	2013-3	Muffler Heat Shield	1 	F031	1/4-20 x 5/8 Hex Bolt	2 	
Precleaner Assembly				F034	5/16-18 x 3/4 Hex Bolt	2 	
25	7840	Hose Clamp (1-5/16 to 2-1/4)	2 	F050	1/4 SAE Washer	1 	
26	2012-1	Air Intake Hose	1 	F164	10-24 x 1/4 x 3/8 SHL Bolt	1 	
27	2088-10	Air Cleaner Assembly (Includes Items # 27-32)	* 	F175	1/2 Split Lock Washer	4 	
28	5091-4	Air Flow Indicator	1 	F184	1/4-20 x 1/2 Hex Bolt, SS	4 	
29	2088-1	Air Cleaner Band	1 	F185	1/4 Internal Star Lock Washer	4 	
30	2090-3	Safety Filter Insert	1 	F201	1/4 Belleville Spring Washer	4 	
31	2090-1	Air Cleaner Cartridge	1 	F439	1/2-13 x 1-3/4 Hex Bolt	4 	
32	2088-2	Air Cleaner Cap	1 				
33	2090-2	Vacuator Valve	1 				
				* Service Part Only			

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

ENGINE GROUP (MODEL MBS)



HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				49	2349-1	Hydro Idler Arm (Includes Items # 50 & 52)	1
1	2358-6	5/16-18 x 1-3/4 Stud	2	50	5830-3	Grease Fitting (45 Deg.)	1
2	2300-2	Parking Brake Hydro Mount, RH	1	51	7201-5	Inner Race (2-1/4)	1
3	5103-2	Pivot Bushing (5/16 ID)	2	52	7201-3	Fiberglide Bearing	2
4	2406-3	Parking Brake Actuator Tube	1	53	2300-5	Spring Mount Plate	1
5	5222	Extension Spring (1/2 x 3-1/4)	1	54	2028-3	Hydro Lockout Rod, LH	1
6	2280	Clevis (3/8)	1	55	9430-1	Spacer Tube	4
7	2406-4	Clevis Pin (5/16 x 1-1/8)	1	56	2025-13	Hydro-Gear ZT3400, LH	1
8	8655-4	Clevis Pin (5/16 x 3/4)	1	57	2026-13	Hydro-Gear ZT3400, RH	1
9	2406-1	Brake Actuator Pull	1	Wheel Assembly			
10	4407-4	Bow Tie Cotter Pin	5	58	2071	Wheel & Tire (22 x 10.50-12)	2
11	5830-4	Grease Fitting (90 Deg.)	1	PTO Coupler (Beginning S/N 2011-109448)			
12	7406-1	Handle Grip, Red	1	59	2010-12	Flex Coupling Guard, RH	1
13	2406-8	Parking Brake Lever Idler Mount (Includes Items # 11 & 12)	1	60	2010-13	Flex Coupling Guard, LH	1
14	2406-5	Parking Brake Stop	1	61	2351-3	Flex Coupler	2
15	2300-1	Parking Brake Hydro Mount, LH	1	62	2351-1	Rubber Coupler	6
16	5281-5	Clevis Pin (1/4 x 0.80)	2	63	2351-4	Inner Flex Coupler	1
17	5280	Clevis (1/4)	2	Fasteners			
18	2406-2	Parking Brake Rod	2	F003	1/4-28 Hex Nut	2	
19	5665-1	Compression Spring (2-1/2)	2	F004	1/4-20 Keps Nut	7	
20	5463	Steering Lever Actuator	2	F005	1/4-20 ESNA Nut	2	
Transaxle Reservoir Assemblies				F009	5/16-18 Whiz Locknut	15	
21	2025-17	Straight Thread Hose Fit	2	F010	5/16-24 ESNA Nut	4	
22	5879-4	Hose Clamp (7/16)	2	F012	3/8-16 Keps Nut	3	
23	2025-14	Hose Channel	1	F013	3/8-16 Whiz Locknut	4	
24	6836-1	Clamp, Double (1/2 x 1/2)	3	F014	3/8-16 ESNA Nut	8	
25	5086-14	Hose (1/4 x 26-1/4")	1	F015	1/2-20 Wheel Lug Nut	8	
26	5879-3	Hose Clamp (1/2)	2	F029	1/4-20 x 1/2 Hex Bolt	4	
27	4024-1	Oil Expansion Reservoir Elbow	2	F031	1/4-20 x 5/8 Hex Bolt	1	
28	2010-9	Hose Reducer (1/2-1/4)	2	F034	5/16-18 x 3/4 Hex Bolt	16	
29	5879-8	Hose Clamp (13/16)	4	F035	5/16-18 x 1-1/4 Hex Bolt	1	
30	5087-1	Hose (1/2 x 1-3/4)	2	F040	3/8-16 x 1-1/2 Hex Bolt	1	
31	2025-1	Oil Expansion Reservoir	2	F043	3/8-16 x 3 Hex Bolt	1	
32	5879-7	Hose Clamp (5/8)	2	F050	1/4 SAE Washer	7	
33	2025-8	Reservoir Bottom Caps	2	F051	3/8 SAE Washer	1	
34	5086-15	Hose (1/4 x 23)	1	F052	5/16 Ext. Star Lock Washer	12	
35	2025	Reservoir Bottle Mount	1	F054	AN960616 Washer	9	
Ground Drive Assemblies				F169	5/16-18 x 1 Carriage Bolt	2	
36	2028-4	Hydro Lockout Rod, RH	1	F171	5/16-18 x 3/8 Set Screw	8	
37	2248	Ground Drive Belt	1	F179	1/4-20 x 1 Hex Bolt	2	
38	2240-2	Drive Pulley (Includes Item # F171)	1	F182	1/4 x 5/8 x 1/8 Washer	4	
39	5267	Retainer Collar (3/4)	1	F183	.312 x .700 x .074 Washer	2	
40	4349-6	Flanged Bearing (1")	1	F211	1/4-20 x 7/8 Hex Bolt	1	
41	2350-13	3/18-16 x 1-3/4 Bolt Grade 5	8	F231	1/4 x 3/4 Woodruff Key (#806)	1	
42	2350-1	Hub, Coupler End	4	F241	.375 x .875 x .10 Washer	1	
43	2350-15	Spacer Bushing	16	F306	3/8-16 x 3/4 Hex Bolt	2	
44	2350-16	Flex Plate	16	F336	3/8-16 Jam Nut	1	
45	2350-12	Coupling Shaft	1	F350	1/4-20 LP Nylock	2	
46	5221-1	Extension Spring (3/4 x 5)	1	F388	3/8-16 x 2-1/2 Hex Bolt	4	
47	4245	Idler Pulley (3/A)	1	F434	5/16-18 x 3-1/2 Hex Bolt	4	
48	5841	Retainer Washer (3/8 x 1-1/4)	1	F435	1/4 x 1/4 x 1-1/4 Key	2	
				F447	1/4 x 1/4 x 1 Key	1	
				F481	Washer 5/16 x 7/8 x .125	12	

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

Effective Date 09-15-10



STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D		ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	
Steering Lever & FSC Assemblies					Transmission Spring Assemblies				
1	5862	FSC Knob	1		36	4199	Transmission Spring Assembly (Includes Items # 37-43, F004, F211, F320 & F352)	*	
2	4170	FSC Lever Assembly (Includes Item # 4)	*						
3	2170-1	Step Washer	1		37	4552	Ball Joint (1/4-28)	2	
4	5830	Grease Fitting	1		38	5194	Plunger Sleeve	2	
5	5214-5	Ball Joint (5/16-24/LH) W/O Stud	1		39	5192-2	Spring Plunger (Female)	2	
6	4213	Control Rod (6-1/4)	1		40	5193	Washer (3/4 x 1 x .085)	2	
7	5214-4	Ball Joint (5/16-24) W/O Stud	1		41	6191	Spring Slide (4-3/4)	2	
8	5214-3	Ball Joint (5/16-24 LH) (Nylon Lined)	2		42	5195	Compress Spring (1 x 5-1/8)	2	
9	4173	Control Rod (5-3/8)	2		43	6196	Spring Slide Cap	2	
10	2212-3	Seal Retainer	2		Fasteners				
11	2212	Transmission Control Arm Stop	2						
12	2212-2	Transmission Control Arm, RH	1			F003	1/4-28 Hex Nut	2	
13	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2			F004	1/4-20 Keps Nut	4	
14	2212-1	Transmission Control Arm, LH	1			F005	1/4-20 ESNA Nut	2	
15	2451-1	Steering Pivot Shaft With Stop	1			F008	5/16-24 Keps Nut	4	
16	5830-3	Grease Fitting (45 Degree)	1			F009	5/16-18 Whiz Locknut	6	
17	8201-3	Fiberglide Bearing	4			F024	5/16-24 Jam Nut	3	
18	2451-3	Speed Control Actuator, LH (Includes Items # 16 & 17)	1			F035	5/16-18 x 1-1/4 Hex Bolt	1	
19	5146	10mm Ball Stud	4			F044	5/16-24 x 3/4 Hex Bolt	2	
20	2215-5	Steering Lever Dampener	2			F049	5/16 SAE Washer	2	
21	2451-2	Speed Control Actuator, RH (Includes Items # 17 & 22)	1			F059	3/8 Wave Spring Washer	1	
22	5830-4	Grease Fitting (90 Deg.)	1			F093	5/16-18 x 1 Hex Bolt	2	
23	4451-4	FSC Friction Actuator	1			F121	5/16-18 x 3/8 x 1 SHL Bolt	1	
24	4219	Extension Spring (3/4 x 6-1/2)	1			F146	1/4-20 Jam Nut	2	
25	5850-2	Handle Grip, Foam (5-1/2)	2			F167	5/16-18 Hex Nut	1	
26	5453-20	Steering Lever Handle (+1") Adjustable / SS (Includes Items # 25, F188, F198 & F345)	2			F183	.312 x .700 x .074 Washer	2	
27	4452-4	Steering Lever Tube W/Tab	2			F188	1/4-20 Self-Locking Nut	4	
28	5450	D-Clip	2			F192	3/8-24 Self-Locking Nut	1	
29	5222	Extension Spring (1/2 x 3-1/4)	2			F198	.250 x .625 x .040 Washer, SS	2	
30	4452-6	Steering Pivot (1/4-20 x 1-5/8)	2			F209	.765 ID x 1.312 OD x .032 Washer	2	
31	4142-1	FSC Cam	1			F211	1/4-20 x 7/8 Hex Bolt	3	
32	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	1			F320	1/8 x 3/4 Split Spring Pin	2	
33	4142-2	FSC Friction Washer (1-1/2 x 1-1/32 x 1/16)	1			F345	1/4-20 x .770 Knurled Bolt	4	
34	9704-3	Pivot Rod Bushing, Plastic	2			F352	5/32 x 1 Heavy Duty Roll Pin	2	
35	2451-4	Steering Shaft Spacer	1			F373	5/16-24 Hex Nut, LH	3	
						F385	1/4 x 1-1/4 Roll Pin	1	
						F386	5/16-18 x 1-1/2 x 3/8 Shoulder Bolt	1	
						F391	1/4-20 x 1/2 Set Screw, SS	2	
						F407	Belleville Washer 3/8 x 1.187, SS	1	
						F427	5/16-18 Flange Nut	1	



* Service Part Only

ELECTRICAL ASSEMBLY (MODEL MBS26)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Assembly				25	5933	Battery Terminal Insl., Red (+)	1 
				26	5932	Battery Terminal Insl., Blk (-)	1 
1	8960-15	Ignition Switch W/Keys (Includes Items # 2, 3 & F349)	1 	27	5844	Battery Hold-Down Bar	1 
2	7854	Plastic Tip, Red	1 	28	2910-1	Battery Shield	1 
3	8960-3	Key Set W/Umbrella	1 	29	5839	Hook Bolt	2 
4	7941-3	Boot, Circuit Breaker	1 	30	8941	Circuit Breaker (30 Amp) (Auto Reset/Sealed)	1 
5	7941-6	Circuit Breaker (15 Amp)	1 	31	6941-1	20 Amp Fuse	1 
6	8990-1	Hourmeter (Sendec)	1 	32	6941-3	10 Amp Fuse	1 
7	8996-2	Red Indicator Light Assembly (Includes Items # 10 & 11)	2 	33	NS	ECU Harness Clip	1
8	8996-10	Amber Indicator Light Assembly	1 	34	NS	ECU (Kohler)	1
9	8536-2	Warning Horn Assembly	1 	35	NS	Relay (Kohler)	1
10	8996-4	Red Indicator Lens (Includes Items # 11 & 12)	2 	36	NS	Fuse Holder (Kohler)	2
11	8996-3	Indicator Bulb (Replacement for P/N 8996-2)	* 	37	5833	Cable Clamp (1/4)	1 
12	8996-6	Amber Indicator Lens	1 	38	2940-6	Wire Harness, 26 EFI	1 
13	6105-3	Harness Clip	3 	39	5942-4	PTO Safety Switch (NO)	1 
14	2940-4	Seat Switch Harness	1 	40	6941-7	Relay Mount	* 
15	6942	Relay Switch 30/40 Amp (NC) (Includes Items # 40 & 41)	3 	41	6941-6	Relay Switch 30/40AMP	* 
16	7948-1	Time Delay Module (Less Harness)	1 	Fasteners			
17	7948-5	Time Delay Harness	1 	F002	10-24 Keps Nut		15 
18	5941-2	Safety Switch	1 	F004	1/4-20 Keps Nut		2 
19	7833-2	Cable Clamp (1 x 1/4)	2 	F009	5/16-18 Whiz Locknut		1 
20	7938	Lead Wire, Battery Charge (Alternator to Starter)	1 	F019	1/4-20 ESNA Wing Nut		2 
21	2940-3	Battery Cable (14")	2 	F026	10-24 x 1/2 PPHMS		13 
22	8012-6	Regulator Adapter Harness	1 	F031	1/4-20 x 5/8 Hex Bolt		2 
23	7910	Battery (12V/340CCA/Dry)	1 	F034	5/16-18 x 3/4 Hex Bolt		1 
24	5975-1	Cable Tie (18# x 3-3/4")	2 	F050	1/4 SAE Washer		4 
				F103	10-24 x 2 PTHMS		2 
				F232	10-32 Keps Nut		2 
				F349	Washer .835 ID 1.122 OD, SS		1 
				F459	10-24 x 2-1/4 Hex Bolt		1 

* Service Part Only

ELECTRICAL ASSEMBLY (MODEL MBS26)



DETAIL A

PUR/RED



GRA

DETAIL B

PUR



PUR/RED

DETAIL C

BLK



PUR PUR/RED

DETAIL D

YEL



WHT

DETAIL E

PUR/RED



GRN

DETAIL F

PUR/RED



BLU

DETAIL G

RED/YEL



BLU

DETAIL H

BLU



PUR/RED

DETAIL I

PUR



WHT

DETAIL J

GRN



BRN

DETAIL K

YEL



BRN

DETAIL L

YEL/BRN



BRN

DETAIL M

ORG



PUR/RED

DETAIL N

WHT



GRN

DETAIL O

BLK



BLK/BRN

DETAIL P

BLK



BLK/BRN

DETAIL Q

YEL/GRN



BLU

DETAIL R

RED



RED

DETAIL S

RED/WHT



RED/WHT

DETAIL T

BLK



BLU

DETAIL U

RED



RED/WHT

DETAIL V

PUR/RED



BRN


Effective Date 09-15-10

Use only genuine Walker® replacement parts.


ELECTRICAL ASSEMBLY (MODEL MBS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Assembly				22	5933	Battery Terminal Insl., Red (+)	1 
1	8960-15	Ignition Switch W/Keys (Includes Items # 2, 3 & F349)	1 	23	5932	Battery Terminal Insl., Blk (-)	1 
2	7854	Plastic Tip, Red	1 	24	5844	Battery Hold-Down Bar	1 
3	8960-3	Key Set W/Umbrella	1 	25	2910-1	Battery Shield	1 
4	7941-3	Boot, Circuit Breaker	1 	26	5839	Hook Bolt	2 
5	7941-6	Circuit Breaker (15 Amp)	1 	27	8941	Circuit Breaker (30 Amp) (Auto Reset/Sealed)	1 
6	8990-1	Hourmeter (Sendec)	1 	28	5833	Cable Clamp (1/4)	1 
7	8996-2	Red Indicator Light Assembly (Includes Items # 8 & 9)	2 	29	2940-5	Wire Harness	1 
8	8996-4	Red Indicator Lens	2 	30	5942-4	PTO Safety Switch (NO)	1 
9	8996-3	Indicator Bulb (Replacement for P/N 8996-2)	* 	31	6941-7	Relay Mount	* 
10	8536-2	Warning Horn Assembly	1 	32	6941-6	Relay Switch 30/40AMP	* 
11	6105-3	Harness Clip	3 	Fasteners			
12	2940-4	Seat Switch Harness	1 	F002	10-24 Keps Nut	12 	
13	6942	Relay Switch 30/40 Amp (NC) (Includes Items # 31 & 32)	3 	F004	1/4-20 Keps Nut	2 	
14	7948-1	Time Delay Module (Less Harness)	1 	F009	5/16-18 Whiz Locknut	1 	
15	7948-5	Time Delay Harness	1 	F019	1/4-20 ESNA Wing Nut	2 	
16	5941-2	Safety Switch	1 	F026	10-24 x 1/2 PPHMS	12 	
17	7833-2	Cable Clamp (1 x 1/4)	2 	F031	1/4-20 x 5/8 Hex Bolt	2 	
18	7938	Lead Wire, Battery Charge (Alternator to Starter)	1 	F034	5/16-18 x 3/4 Hex Bolt	1 	
19	2940-3	Battery Cable (14")	2 	F050	1/4 SAE Washer	4 	
20	7910	Battery (12V/340CCA/Dry)	1 	F232	10-32 Keps Nut	4 	
21	5975-1	Cable Tie (18# x 3-3/4")	2 	F349	Washer .835 ID 1.122 OD, SS	1 	
				*	Service Part Only		

ELECTRICAL ASSEMBLY (MODEL MBS)



END VIEWS ARE SHOWN FROM BACK OF PLUG



DETAIL A



DETAIL B



DETAIL C




DETAIL D




DETAIL E




DETAIL F




DETAIL G




DETAIL H




DETAIL I




DETAIL J



DETAIL K



DETAIL L




DETAIL M



DETAIL N



DETAIL O



Effective Date 09-15-10

Use only genuine **Walker®** replacement parts.


60 INCH COMPLETE CARRIER FRAME ASSEMBLY (P/N 2911-1)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Spring and Pivot Mount Components				36	2214-10	Rod End, Female (3/8-24)	4
1	2744-1	Spring Clip Bracket	1	37	2722-3	Pivot Shaft	2
2	5975-3	Cable Tie (50# x 7")	2	38	2655	Lift Chain	4
3	5743-1	Spring Cover	2	39	4407-4	Bow Tie Cotter Pin	2
4	5743-6	Extension Spring (1-1/2 x 7-3/4) (Includes Items # 2, F117 & F166)	2	40	2215-4	Height Adjustment Rod	2
5	5743-3	Eye Bolt (3/8-16 x 2)	2	41	5146	10mm Ball Stud	4
6	2723	Counter Weight Spring Mount	2	42	2215	Gas Spring Assembly	2
7	2723-5	Locking Arm, LH (Includes Item # F432)	1	43	2721	Lifting Arm (Includes Item # 8)	1
8	5830	Grease Fitting	10	44	2721-2	Lifting Cross Tube	1
9	2667-1	Pivot Mount, LH (Includes Item # 8)	1	45	2723-3	Height Adjustment Arm (Includes Item # 46)	1
10	2723-4	Pivot Shaft	2	46	5850-3	Handle Grip, Foam (3-1/4)	1
11	2667-2	Pivot Mount, RH (Includes Item # 8)	1	47	2722-2	Deck Height Adjustment Trigger (Includes Item # 8)	1
12	2723-6	Locking Arm, RH (Includes Item # F432)	1	Fasteners			
Carrier Frame Components				F004	1/4-20 Keps Nut	6	
13	2215-2	Gas Spring Cover, RH	1	F009	5/16-18 Whiz Locknut	12	
14	2723-2	Outer Height Adjustment Plate	1	F013	3/8-16 Whiz Locknut	14	
15	7775-5	Lock Pin (5/16)	2	F014	3/8-16 ESNA Nut	2	
16	2720-3	Height Adjustment Spacer	4	F035	5/16-18 x 1-1/4 Hex Bolt	2	
17	2723-1	Inner Height Adjustment Plate	1	F038	3/8-16 x 1 Hex Bolt	2	
18	2215-3	Gas Spring Cover, LH	1	F039	3/8-16 x 1-1/4 Hex Bolt	2	
19	8740	Deck Pin Bushing (3/4 ID)	4	F040	3/8-16 x 1-1/2 Hex Bolt	5	
20	2911-3	60SD Carrier Frame	1	F048	1/2 SAE Washer	2	
21	8811-25	Tilt Bar W/Grip (35") (Includes Item # 22)	1	F050	1/4 SAE Washer	6	
22	5850-5	Handle Grip (1 x 1 x 3-3/4)	1	F071	3/4 External Snap Ring	2	
Caster Wheel Components				F090	1/4-20 x 2-1/2 Hex Bolt	4	
23	8769-8	Dust Cap, Deck Caster	2	F117	Retainer Ring	2	
24	8769-6	Bearing Cone (1" ID)	4	F132	1/4-20 x 2-3/4 Hex Bolt	2	
25	8769-5	Bearing Cup (2 x 1-5/8)	4	F166	Retainer Ring	2	
26	8769-7	Seal	2	F205	5/16-18 x 1/4 Set Screw (Knurl Point)	2	
27	2770	Caster Wheel Fork	2	F215	3/8-16 x 1/2 x 1/2 S Bolt	2	
28	7038	Tail Wheel Axle (3/4 x 5-9/16)	2	F218	7/16 Split Lock Washer	4	
29	8037-1	Seal, Outer (1-3/4 x 1-1/8)	2	F219	7/16-14 x 1-1/4 Hex Bolt	4	
30	8037	Bearing Cone (3/4 ID)	4	F226	5/16-18 x 7/8 Hex Bolt	4	
31	8035	Tail Wheel & Tire (13 x 5.00-6) (W/Bearing Race)	2	F241	.375 x .875 x .10 Washer	18	
32	8768-2	Seal, Reverse Lip	2	F263	1-1/4 External Snap Ring	6	
33	8038-1	Spacer, Tail Wheel Axle (.750 x ID x 1.125 OD)	2	F268	5/16-18 x 3 Hex Bolt	1	
34	8039	Nut, Tail Wheel Axle	2	F298	3/8-24 Jam Nut	4	
Deck Lift Components				F344	3/4-16 Slotted Hex Nut	2	
35	2722-1	Deck Height Adjustment, LH (Includes Item # 8)	1	F347	3/4 SAE Washer	2	
				F348	1/8 x 1-1/2 Cotter Pin	2	
				F378	3/8-16 x 6 Hex Bolt	1	
				F432	3/16 x 1/2 Split Spring Pin	2	
				F436	3/16 x 1-1/8 Spring Pin	4	
				F437	Clevis Pin (1/4 x 1)	2	
				F438	5/16-18 x 2-3/4 Hex Bolt	1	

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

Effective Date 09-15-10



DSD60 DECK ASSEMBLY (P/N 2910-5)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Deck Housing Components				47	2245-1	Idler Pulley	1 
1	2110	Hood Latch Assembly	2 		2245-5	Idler Pulley Assembly (Includes Items # 37, 38, 47 & F445)	* 
2	2786-4	Locking Finger	2 	48	5830	Grease Fitting	4 
3	2786-3	Rubber Mat (2 x 7)	2 	49	2724-6	Belt Tensioner Clevis	1 
4	2786-2	Rubber Mat (7 x 9-1/2)	2 	50	8655-4	Clevis Pin (5/16 x 3/4)	1 
5	4845	Rubber Bumper (1.0 x .625)	4 	51	4407-4	Bow Tie Cotter Pin	1 
6	2786-5	Footrest, DSD60 (Includes Items # 3 & 4)	1 	52	7201-3	Fiberglide Bearing	2 
7	2703-5	Knob, 10-24 x 1/2	4 	53	7201-5	Inner Race (2-1/4)	1 
8	2724-11	Spindle Cover	2 	54	2221	Extension Spring (1 x 4)	1 
9	5162-11	Roller Wheel (5") (Includes Item # F059)	2 	55	2724-12	Idler Arm (Includes Item # 48)	1 
10	8490	Roller Wheel Axle Bolt	2 	Blade Spindle Components			
11	NS	Deck Serial Number Plate	1	56	2052	Blade Spindle	3 
12	8735-10	Rubber Mat (5 x 6)	2 	57	7705-15	Hi-Lift Blade 21" (RH Rotation)	3 
13	2910-4	60SD Deck Housing (Includes Item # 12)	1 	Fasteners			
14	2720-5	Deck Height Adjustment Clevis	2 		F002	10-24 Keps Nut	10 
15	8910-5	Tie Down Strap	2 		F004	1/4-20 Keps Nut	15 
16	6715-4	Axle Spacer Tube	4 		F005	1/4-20 ESNA Nut	12 
17	6715-3	Roller Wheel Bearing	8 		F009	5/16-18 Whiz Locknut	14 
18	6715-2	Roller Wheel	4 		F012	3/8-16 Keps Nut	2 
19	2720-2	DSD60 Baffle	1 		F013	3/8-16 Whiz Locknut	24 
20	2703-3	5/16-18 Torque Knob	1 		F014	3/8-16 ESNA Nut	2 
21	2724-8	Tensioner Guide	1 		F025	10-24 x 3/8 PPHMS	10 
22	2707	60SD Skid Bar	1 		F028	10-24 x 3/4 PPHMS	2 
23	2705-8	Front Backup Plate	1 		F029	1/4-20 x 1/2 Hex Bolt	11 
24	2705-7	Center Backup Plate	1 		F031	1/4-20 x 5/8 Hex Bolt	14 
25	2705-9	Rear Backup Plate	1 		F033	1/4-20 x 1 PTH Bolt	12 
26	2809-2	Rubber Shield	1 		F034	5/16-18 x 3/4 Hex Bolt	6 
27	2705-10	Chute Frame / Outer	1 		F039	3/8-16 x 1-1/4 Hex Bolt	18 
28	8670-9	Tilt-Up Hook	1 		F041	3/8-16 x 1-3/4 Hex Bolt	3 
Blade Drive Components					F043	3/8-16 x 3 Hex Bolt	1 
29	2618-1	Cover, PTO Shaft Guard	1 		F045	3/16 x 3/16 x 3/4 Key	3 
30	2620-3	Rubber Flap	1 		F048	1/2 SAE Washer	3 
31	2620-2	Backing Plate	1 		F049	5/16 SAE Washer	2 
32	2619-1	PTO Shaft Guard	1 		F050	1/4 SAE Washer	13 
	2618-2	PTO Shaft Guard Assembly (Includes Items # 29-32, F002, F025 & F028)	* 		F051	3/8 SAE Washer	2 
33	5270	Bearing W/Collar (1")	2 		F059	3/8 Wave Spring Washer	4 
34	2726	PTO Bearing Housing	1 		F067	3/16 x 3/16 x 1 Key	1 
35	2726-1	PTO Drive Shaft	1 		F075	5/16-18 x 1/2 SQH Set Screw	2 
36	2240-1	Drive Pulley (Includes Items # F075 & F435)	1 		F108	3/8-16 x 2 Hex Bolt	1 
37	2265	Bearing (20mm)	1 		F206	#2 x 3/16 Drive Pin	2 
38	2245-4	Idler Pulley Shaft	1 		F211	1/4-20 x 7/8 Hex Bolt	2 
39	2725-1	Tilted Idler Mount	1 		F241	.375 x .875 x .10 Washer	2 
40	8285-3	U-Joint Shaft Assembly, Spline (Includes Item # F318)	1 		F265	1/2-20 x 1-1/2 Hex Bolt	3 
41	4245-1	Idler Pulley (4/Flat)	1 		F276	5/8-11 Jam Nut	3 
42	2240	Blade Drive Pulley (3-1/2)	3 		F318	3/8-16 x 3/4 SQH Set Screw	2 
43	8245	Idler Pulley (6")	2 		F405	3/8-16 x 1-1/2 FHA Screw, SS	2 
44	2350-5	Washer (3/8-16 Tap 1/4 Thk)	1 		F408	7/16-20 Jam Nut	2 
45	2731	Blade Drive Belt (R3VX1250)	1 		F435	1/4 x 1/4 x 1-1/4 Key	1 
46	5841	Retainer Washer (3/8 x 1-1/4)	1 		F445	1-7/8 Internal Snap Ring	1 
					F458	Washer 1-1/4 x 5/8 x 3/16	3 
					F478	5/16-18 x 3-1/4 Hex Bolt	4 

* Service Part Only

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

DSD60 DECK ASSEMBLY (P/N 2910-5)



Effective Date 09-15-10

Use only genuine **Walker®** replacement parts.

52 INCH COMPLETE CARRIER FRAME ASSEMBLY (P/N 2911-4)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Spring and Pivot Mount Components				36	2214-10	Rod End, Female (3/8-24)	4
1	2744-1	Spring Clip Bracket	1	37	2722-4	Pivot Shaft	2
2	5975-3	Cable Tie (50# x 7")	2	38	2655	Lift Chain	4
3	5743-1	Spring Cover	2	39	4407-4	Bow Tie Cotter Pin	2
4	5743-6	Extension Spring (1-1/2 x 7-3/4) (Includes Items # 2, F117 & F166)	2	40	2215-4	Height Adjustment Rod	2
5	5743-3	Eye Bolt (3/8-16 x 2)	2	41	5146	10mm Ball Stud	4
6	2723	Counter Weight Spring Mount	2	42	2215	Gas Spring Assembly	2
7	2723-5	Locking Arm, LH (Includes Item # F432)	1	43	2721-3	Lifting Arm (Includes Item # 8)	1
8	5830	Grease Fitting	10	44	2721-2	Lifting Cross Tube	1
9	2667-1	Pivot Mount, LH (Includes Item # 8)	1	45	2723-7	Height Adjustment Arm (Includes Item # 46)	1
10	2723-4	Pivot Shaft	2	46	5850-3	Handle Grip, Foam (3-1/4)	1
11	2667-2	Pivot Mount, RH (Includes Item # 8)	1	47	2722-6	Deck Height Adjustment Trigger (Includes Item # 8)	1
12	2723-6	Locking Arm, RH (Includes Item # F432)	1	Fasteners			
Carrier Frame Components				F004	1/4-20 Keps Nut	6	
13	2215-2	Gas Spring Cover, RH	1	F009	5/16-18 Whiz Locknut	12	
14	2723-2	Outer Height Adjustment Plate	1	F013	3/8-16 Whiz Locknut	14	
15	7775-5	Lock Pin (5/16)	2	F014	3/8-16 ESNA Nut	2	
16	2720-3	Height Adjustment Spacer	4	F035	5/16-18 x 1-1/4 Hex Bolt	2	
17	2723-1	Inner Height Adjustment Plate	1	F038	3/8-16 x 1 Hex Bolt	2	
18	2215-3	Gas Spring Cover, LH	1	F039	3/8-16 x 1-1/4 Hex Bolt	2	
19	8740	Deck Pin Bushing (3/4 ID)	4	F040	3/8-16 x 1-1/2 Hex Bolt	5	
20	2911-5	DRD52 Carrier Frame	1	F048	1/2 SAE Washer	2	
21	8811-25	Tilt Bar W/Grip (35") (Includes Item # 22)	1	F050	1/4 SAE Washer	6	
22	5850-5	Handle Grip (1 x 1 x 3-3/4)	1	F071	3/4 External Snap Ring	2	
Caster Wheel Components				F090	1/4-20 x 2-1/2 Hex Bolt	4	
23	8769-8	Dust Cap, Deck Caster	2	F117	Retainer Ring	2	
24	8769-6	Bearing Cone (1" ID)	4	F132	1/4-20 x 2-3/4 Hex Bolt	2	
25	8769-5	Bearing Cup (2 x 1-5/8)	4	F166	Retainer Ring	2	
26	8769-7	Seal	2	F205	5/16-18 x 1/4 Set Screw (Knurl Point)	2	
27	2770	Caster Wheel Fork	2	F215	3/8-16 x 1/2 x 1/2 S Bolt	2	
28	7038	Tail Wheel Axle (3/4 x 5-9/16)	2	F218	7/16 Split Lock Washer	4	
29	8037-1	Seal, Outer (1-3/4 x 1-1/8)	2	F219	7/16-14 x 1-1/4 Hex Bolt	4	
30	8037	Bearing Cone (3/4 ID)	4	F226	5/16-18 x 7/8 Hex Bolt	4	
31	8035	Tail Wheel & Tire (13 x 5.00-6) (W/Bearing Race)	2	F241	.375 x .875 x .10 Washer	18	
32	8768-2	Seal, Reverse Lip	2	F263	1-1/4 External Snap Ring	6	
33	8038-1	Spacer, Tail Wheel Axle (.750 x ID x 1.125 OD)	2	F268	5/16-18 x 3 Hex Bolt	1	
34	8039	Nut, Tail Wheel Axle	2	F298	3/8-24 Jam Nut	4	
Deck Lift Components				F344	3/4-16 Slotted Hex Nut	2	
35	2722-5	Deck Height Adjustment, LH (Includes Item # 8)	1	F347	3/4 SAE Washer	2	
				F348	1/8 x 1-1/2 Cotter Pin	2	
				F378	3/8-16 x 6 Hex Bolt	1	
				F432	3/16 x 1/2 Split Spring Pin	2	
				F436	3/16 x 1-1/8 Spring Pin	4	
				F437	Clevis Pin (1/4 x 1)	2	
				F438	5/16-18 x 2-3/4 Hex Bolt	1	

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

Effective Date 09-15-10



DRD52 DECK ASSEMBLY (P/N 2910-6)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Deck Housing Components				41	2724-6	Belt Tensioner Clevis	1
1	2786-5	Footrest, DRD52 (Includes Items # 2 & 3)	1	42	8655-4	Clevis Pin (5/16 x 3/4)	1
2	2786-3	Rubber Mat (2 x 7)	2	43	4407-4	Bow Tie Cotter Pin	1
3	2786-2	Rubber Mat (7 x 9-1/2)	2	44	5830	Grease Fitting	4
4	2786-4	Locking Finger	2	45	7201-3	Fiberglide Bearing	2
5	2110	Hood Latch Assembly	2	46	7201-5	Inner Race (2-1/4)	1
6	2703-5	Knob, 10-24 x 1/2	4	47	5221-1	Extension Spring (3/4 x 5)	1
7	2724-9	Spindle Cover	2	48	2724-12	Idler Arm (Includes Item # 44)	1
8	4845	Rubber Bumper (1.0 x .625)	4	Blade Spindle Components			
9	9772	Roller Wheel Assembly (2-1/2)	2	49	2052	Blade Spindle	3
		(Includes Item # F059)		50	7705-14	Blade (18.333)	3
10	8490	Roller Wheel Axle Bolt	2	Fasteners			
11	NS	Deck Serial Number Plate	1	F002	10-24 Keps Nut	12	
12	8735-10	Rubber Mat (5 x 6)	2	F004	1/4-20 Keps Nut	6	
13	2910-3	DRD52 Deck Housing (Includes Item # 12)	1	F009	5/16-18 Whiz Locknut	14	
14	2720-5	Deck Height Adjustment Clevis	2	F012	3/8-16 Keps Nut	1	
15	6715-3	Roller Wheel Bearing	8	F013	3/8-16 Whiz Locknut	22	
16	6715-4	Axle Spacer Tube	4	F025	10-24 x 3/8 PPHMS	10	
17	6715-2	Roller Wheel	4	F028	10-24 x 3/4 PPHMS	2	
18	8910-5	Tie Down Strap	2	F029	1/4-20 x 1/2 Hex Bolt	4	
19	2703-3	5/16-18 Torque Knob	1	F031	1/4-20 x 5/8 Hex Bolt	6	
20	2724-8	Tensioner Guide	1	F034	5/16-18 x 3/4 Hex Bolt	6	
21	8670-9	Tilt-Up Hook	1	F039	3/8-16 x 1-1/4 Hex Bolt	16	
Blade Drive Components				F041	3/8-16 x 1-3/4 Hex Bolt	3	
22	2618-1	Cover, PTO Shaft Guard	1	F043	3/8-16 x 3 Hex Bolt	1	
23	2620-3	Rubber Flap	1	F045	3/16 x 3/16 x 3/4 Key	3	
24	2620-2	Backing Plate	1	F048	1/2 SAE Washer	3	
25	2619-2	PTO Shaft Guard	1	F049	5/16 SAE Washer	2	
	2618-3	PTO Shaft Guard Assembly	*	F050	1/4 SAE Washer	2	
		(Includes Items # 22-25, F002, F025 & F028)		F051	3/8 SAE Washer	3	
26	5270	Bearing W/Collar (1")	2	F059	3/8 Wave Spring Washer	2	
27	2726	PTO Bearing Housing	1	F067	3/16 x 3/16 x 1 Key	1	
28	2726-1	PTO Drive Shaft	1	F075	5/16-18 x 1/2 SQH Set Screw	2	
29	2240-4	Drive Pulley	1	F108	3/8-16 x 2 Hex Bolt	1	
		(Includes Items # F075 & F435)		F206	#2 x 3/16 Drive Pin	2	
30	2265	Bearing (20mm)	1	F241	.375 x .875 x .10 Washer	2	
31	2245-4	Idler Pulley Shaft	1	F265	1/2-20 x 1-1/2 Hex Bolt	3	
32	2725-1	Tilted Idler Mount	1	F276	5/8-11 Jam Nut	3	
33	8285-4	U-Joint Shaft Assembly, Spline	1	F318	3/8-16 x 3/4 SQH Set Screw	2	
		(Includes Item # F318)		F405	3/8-16 x 1-1/2 FHA Screw, SS	2	
34	4245-1	Idler Pulley (4/Flat)	1	F408	7/16-20 Jam Nut	2	
35	2240-3	Blade Drive Pulley (3-1/8)	3	F435	1/4 x 1/4 x 1-1/4 Key	1	
36	8245	Idler Pulley (6")	2	F445	1-7/8 Internal Snap Ring	1	
37	2350-5	Washer (3/8-16 Tap 1/4 Thk)	1	F458	Washer 1-1/4 x 5/8 x 3/16	3	
38	2731-2	Blade Drive Belt (1150L4-K)	1	F478	5/16-18 x 3-1/4 Hex Bolt	4	
39	5841	Retainer Washer (3/8 x 1-1/4)	1				
40	2245-2	Idler Pulley	1				

* Service Part Only

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

DRD52 DECK ASSEMBLY (P/N 2910-6)




Effective Date 09-15-10


MULCHING KIT

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D		ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	
Mulching Kit					Fasteners				
1	7705-16	Blade, 21" Low Lift	3		F004		1/4-20 Keps Nut	13	
2	2691-7	Left Hand Baffle	1		F029		1/4-20 x 1/2 Hex Bolt	13	
3	2691-6	Center Baffle	1		F048		1/2 SAE Washer	3	
4	2691-8	Right Hand Baffle	1		F265		1/2-20 x 1-1/2 Hex Bolt	3	


MULCHING KIT




WIRING SCHEMATIC (MODEL MBS26)



WIRING SCHEMATIC (MODEL MBS26)



WIRING SCHEMATIC (MODEL MBS)



Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

LIMITED WARRANTY FOR WALKER MODEL MBS26 AND MBS RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within one (1) year after date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine
Hydro-Gear Transaxles
Battery
Tires

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

2. WHAT THIS WARRANTY DOES NOT COVER:

- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Owner's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sound - Model MBS

Sound Test

**Lwa
100**

Sound test conducted was in accordance with 2000/14/EC and was performed on 6 July 07 under the conditions listed:

General Condition: Clear

Temperature: 90 (F)° 32 (C)°

Wind Speed: < 5 mph (< 8 kmh)

Humidity: 20%

Barometric Pressure: 83.8 kPA

Vibration - Model MBS

Vibration Level

0.2g

Vibration levels at the operators handles were measured in the vertical, lateral, and longitudinal directions using calibrated vibration test equipment.

Tests were performed on 6 July 07 under the conditions listed:

General Condition: Clear

Temperature: 90 (F)° 32 (C)°

Wind Speed: < 5 mph (< 8 kmh)

Humidity: 20%

Barometric Pressure: 83.8 kPA

WALKER MOWERS™

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 091510 PRINTED IN USA www.walkermowers.com ©2011 WALKER MFG. CO